



EN

Control

L1.01 - Expert 2.0

L1.02 - Expert 2.0

099-00L100-EW501

Observe additional system documents!

05.10.2016

**Register now
and benefit!
Jetzt Registrieren
und Profitieren!**

www.ewm-group.com



General instructions

WARNING



Read the operating instructions!

The operating instructions provide an introduction to the safe use of the products.

- Read and observe the operating instructions for all system components, especially the safety instructions and warning notices!
- Observe the accident prevention regulations and any regional regulations!
- The operating instructions must be kept at the location where the machine is operated.
- Safety and warning labels on the machine indicate any possible risks. Keep these labels clean and legible at all times.
- The machine has been constructed to state-of-the-art standards in line with any applicable regulations and industrial standards. Only trained personnel may operate, service and repair the machine.
- Technical changes due to further development in machine technology may lead to a differing welding behaviour.



In the event of queries on installation, commissioning, operation or special conditions at the installation site, or on usage, please contact your sales partner or our customer service department on +49 2680 181-0.

A list of authorised sales partners can be found at www.ewm-group.com.

Liability relating to the operation of this equipment is restricted solely to the function of the equipment. No other form of liability, regardless of type, shall be accepted. This exclusion of liability shall be deemed accepted by the user on commissioning the equipment.

The manufacturer is unable to monitor whether or not these instructions or the conditions and methods are observed during installation, operation, usage and maintenance of the equipment.

An incorrectly performed installation can result in material damage and injure persons as a result. For this reason, we do not accept any responsibility or liability for losses, damages or costs arising from incorrect installation, improper operation or incorrect usage and maintenance or any actions connected to this in any way.

© EWM AG

**Dr. Günter-Henle-Straße 8
56271 Mündersbach
Germany**

The copyright to this document remains the property of the manufacturer.

Copying, including extracts, only permitted with written approval.

The content of this document has been prepared and reviewed with all reasonable care. The information provided is subject to change; errors excepted.

1 Contents

| | | |
|----------|--|-----------|
| 1 | Contents..... | 3 |
| 2 | For your safety | 5 |
| 2.1 | Notes on the use of these operating instructions | 5 |
| 2.1.1 | Explanation of icons | 6 |
| 2.2 | Part of the complete documentation | 7 |
| 3 | Intended use | 8 |
| 3.1 | Use and operation solely with the following machines | 8 |
| 3.2 | Applications..... | 8 |
| 3.3 | Documents which also apply | 9 |
| 3.4 | Machine variants..... | 9 |
| 3.5 | Software version | 9 |
| 4 | Quick overview | 10 |
| 4.1 | Machine control – Operating elements | 10 |
| 4.1.1 | Screen icons..... | 11 |
| 4.1.2 | Machine display..... | 13 |
| 4.1.2.1 | Actual values, nominal values, hold values | 13 |
| 4.1.3 | Main screen | 13 |
| 4.1.3.1 | Main screen variants | 14 |
| 4.1.4 | Initial screen | 14 |
| 4.1.4.1 | Basic settings for operation with two wire feeders (P10) | 15 |
| 4.1.4.2 | Change system language | 15 |
| 5 | Operating the machine control..... | 16 |
| 5.1 | Central control button..... | 16 |
| 5.2 | Direct access keys | 16 |
| 5.3 | Context-dependent push-buttons | 16 |
| 5.4 | Machine configuration (system) | 17 |
| 5.4.1 | Power-saving mode (Standby) | 17 |
| 5.4.2 | Access permission (Xbutton)..... | 18 |
| 5.4.2.1 | User information..... | 18 |
| 5.4.2.2 | Activating the Xbutton rights | 18 |
| 5.4.3 | Status information..... | 19 |
| 5.4.3.1 | Errors and warnings | 19 |
| 5.4.3.2 | Running time | 19 |
| 5.4.3.3 | System components..... | 19 |
| 5.4.4 | System settings | 20 |
| 5.4.4.1 | Date..... | 20 |
| 5.4.4.2 | Time | 20 |
| 5.4.4.3 | Water block | 20 |
| 5.4.4.4 | Special parameter | 21 |
| 5.4.5 | Xnet machine..... | 22 |
| 5.4.5.1 | Clear system memory | 22 |
| 5.4.5.2 | Reset to factory settings | 22 |
| 5.4.6 | Operating panel settings | 23 |
| 5.4.7 | Aligning the cable resistance..... | 24 |
| 5.5 | Offline data transfer (USB) | 26 |
| 5.5.1 | Save JOB(s) | 26 |
| 5.5.2 | Load JOB(s) | 26 |
| 5.5.3 | Save configuration..... | 26 |
| 5.5.3.1 | Master configuration..... | 26 |
| 5.5.3.2 | Individual configuration | 26 |
| 5.5.4 | Load configuration | 26 |
| 5.5.4.1 | Master configuration..... | 26 |
| 5.5.4.2 | Individual configuration | 26 |
| 5.5.5 | Load languages and texts | 26 |
| 5.5.6 | Record on USB drive..... | 27 |
| 5.5.6.1 | Register USB drive..... | 27 |

| | | |
|-----------|---|-----------|
| 5.5.6.2 | Start recording..... | 27 |
| 5.5.6.3 | Stop recording..... | 27 |
| 5.6 | Welding task administration (Menu)..... | 28 |
| 5.6.1 | JOB selection (material/wire/gas)..... | 28 |
| 5.6.2 | JOB manager..... | 28 |
| 5.6.2.1 | Copy JOB to number..... | 28 |
| 5.6.2.2 | Reset current JOB..... | 28 |
| 5.6.2.3 | Reset all JOBS..... | 28 |
| 5.6.3 | Program sequence..... | 29 |
| 5.6.3.1 | MIG/MAG welding..... | 30 |
| 5.6.3.2 | Advanced settings..... | 31 |
| 5.6.3.3 | Overview of the welding parameter switching options..... | 32 |
| 5.6.3.4 | TIG welding..... | 34 |
| 5.6.3.5 | MMA welding..... | 35 |
| 5.6.4 | Setup mode..... | 36 |
| 5.6.5 | Welding data monitoring..... | 37 |
| 5.6.6 | JOB display setting..... | 37 |
| 5.7 | Change welding procedure (Arc)..... | 38 |
| 5.8 | Online data transfer (network)..... | 39 |
| 5.8.1 | Wired local network (LAN)..... | 39 |
| 5.8.2 | Wireless local network (WiFi)..... | 39 |
| 6 | Welding procedure..... | 40 |
| 6.1 | MIG/MAG welding..... | 40 |
| 6.1.1 | Operating modes..... | 40 |
| 6.1.1.1 | Explanation of signs and functions..... | 40 |
| 6.1.1.2 | MIG/MAG automatic cut-out..... | 52 |
| 6.1.2 | coldArc / coldArc puls..... | 53 |
| 6.1.3 | forceArc / forceArc puls..... | 54 |
| 6.1.4 | rootArc/rootArc puls..... | 55 |
| 6.1.5 | pipeSolution..... | 55 |
| 6.1.6 | Standard MIG/MAG torch..... | 56 |
| 6.1.7 | MIG/MAG special-torches..... | 56 |
| 6.1.7.1 | Program and up/down operation..... | 56 |
| 6.1.7.2 | Switching between Push/Pull and intermediate drive..... | 57 |
| 6.2 | TIG welding..... | 58 |
| 6.2.1 | Function sequences/operating modes..... | 58 |
| 6.2.1.1 | Explanation of signs and functions..... | 58 |
| 6.2.2 | TIG automatic cut-out..... | 61 |
| 6.2.3 | TIG arc ignition..... | 62 |
| 6.2.3.1 | Liftarc..... | 62 |
| 6.3 | MMA welding..... | 63 |
| 6.3.1 | Hotstart..... | 63 |
| 6.3.2 | Antistick..... | 63 |
| 6.3.3 | Air arc gouging..... | 63 |
| 7 | Rectifying faults..... | 64 |
| 7.1 | Display machine control software version..... | 64 |
| 7.2 | Error messages (power source)..... | 64 |
| 7.3 | Resetting JOBS (welding tasks) to the factory settings..... | 65 |
| 8 | Appendix A..... | 66 |
| 8.1 | Parameter overview – setting information..... | 66 |
| 8.1.1 | MIG/MAG welding..... | 66 |
| 8.1.2 | TIG welding..... | 67 |
| 8.1.3 | MMA welding..... | 68 |
| 9 | Appendix B..... | 69 |
| 9.1 | JOB-List..... | 69 |
| 10 | Appendix C..... | 76 |
| 10.1 | Overview of EWM branches..... | 76 |

2 For your safety

2.1 Notes on the use of these operating instructions

DANGER

Working or operating procedures which must be closely observed to prevent imminent serious and even fatal injuries.

- Safety notes include the "DANGER" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol on the edge of the page.

WARNING

Working or operating procedures which must be closely observed to prevent serious and even fatal injuries.

- Safety notes include the "WARNING" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol in the page margin.

CAUTION

Working or operating procedures which must be closely observed to prevent possible minor personal injury.

- The safety information includes the "CAUTION" keyword in its heading with a general warning symbol.
- The risk is explained using a symbol on the edge of the page.

























Special technical points which users must observe.


Instructions and lists detailing step-by-step actions for given situations can be recognised via bullet points, e.g.:

- Insert the welding current lead socket into the relevant socket and lock.

2.1.1 Explanation of icons

| Symbol | Description | Symbol | Description |
|---|---|---|---------------------------------|
|  | Indicates technical aspects which the user must observe. |  | Activate and release/tap/tip |
|  | Switch off machine |  | Release |
|  | Switch on machine |  | Press and keep pressed |
| | |  | Switch |
|  | Wrong |  | Turn |
|  | Correct |  | Numerical value – adjustable |
|  | Menu entry |  | Signal light lights up in green |
|  | Navigating the menu |  | Signal light flashes green |
|  | Exit menu |  | Signal light lights up in red |
|  | Time representation (e.g.: wait 4 s/activate) |  | Signal light flashes red |
|  | Interruption in the menu display (other setting options possible) | | |
|  | Tool not required/do not use | | |
|  | Tool required/use | | |

2.2 Part of the complete documentation

 **These operating instructions are part of the complete documentation and valid only in combination with all other parts of these instructions! Read and observe the operating instructions for all system components, especially the safety instructions!**

The illustration shows a general example of a welding system.




Figure 2-1

| Item | Documentation |
|------|--|
| A.1 | Wire feeder |
| A.2 | Conversion instructions |
| A.3 | Power source |
| A.4 | Cooling unit, voltage converter, tool box etc. |
| A.5 | Trolley |
| A.6 | Welding torch |
| A.7 | Remote control |
| A.8 | Control |
| A | Complete documentation |

3 Intended use

WARNING



Hazards due to improper usage!

The machine has been constructed to the state of the art and any regulations and standards applicable for use in industry and trade. It may only be used for the welding procedures indicated at the rating plate. Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!

- The equipment must only be used in line with its designated purpose and by trained or expert personnel!
- Do not improperly modify or convert the equipment!

3.1 Use and operation solely with the following machines

This description may only be applied to machines with the Expert 2.0 machine control.

3.2 Applications

| Machine series | Main process | | | | | | | Secondary process | | |
|----------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| | Standard MIG/MAG welding | | | | Pulsed MIG/MAG welding | | | TIG welding (lift arc) | MMA welding | Gouging |
| | forceArc | rootArc | coldArc | pipeSolution | forceArc puls | rootArc puls | coldArc puls | | | |
| alpha Q puls MM | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Phoenix puls MM | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Taurus Synergic S MM | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |

☒ possible

☐ not possible

3.3 Documents which also apply

- Operating instructions for the connected welding machines
- Documents of the optional expansions

3.4 Machine variants

| Welding machine control | Expert 2.0 | Expert 2.0 LG | Expert 2.0 WLG |
|-------------------------|-----------------------|------------------|----------------------------|
| Description | No network connection | Version with LAN | Version with LAN and Wi-Fi |

3.5 Software version

These instructions apply to the following software version:
0.0.7.1



The machine control software version is shown on the screen during the start process > see 4.1.4 chapter.

4 Quick overview

4.1 Machine control – Operating elements








































Figure 4-1

| Item | Symbol | Description |
|------|--------|---|
| 1 | | System push-button To display and configure the system settings > see 5.4 chapter. |
| 2 | | Machine display Graphical machine display showing all machine functions, menus and parameters with their values > see 4.1.2 chapter. |
| 3 | | USB push-button To use and configure the USB interface > see 5.5 chapter. |
| 4 | | USB interface for offline data transfer Connection for storage medium with a USB interface and without independent power supply (flash drives, in particular). |
| 5 | | Control button Central control button to be pressed or turned > see 5.1 chapter. |
| 6 | | Control button for arc length correction/choke effect (arc dynamics) Control button for operation of the parameters by pressing and turning. Press: Switch between parameters. Turn: Set the parameter values. |
| 7 | | Interface (Xbutton) Welding access based on user-defined rights to protect against unauthorised use > see 5.4.2 chapter. |
| 8 | | Context-dependent push-button > see 5.3 chapter |

| Item | Symbol | Description |
|------|---|--|
| 9 |  | Arc push-button This push-button has a double function: <ul style="list-style-type: none"> Initial state of main screen: Switching of the welding procedure based on the selected material, gas and welding consumable. Initial state of any sub-menu: Display switches back to the main screen. |
| 10 |  | Menu push-button To organise welding tasks and configure process parameters. |

4.1.1 Screen icons

| Symbol | Description |
|---|---|
|  | Shielding gas |
|  | Material type |
|  | Wire inching |
|  | Wire return |
|  | Advanced settings |
|  | Setup mode |
|  | Non-latched operating mode |
|  | Special non-latched operating mode |
|  | Latched operating mode |
|  | Special latched operating mode |
| JOB | Welding task |
| sup | superPuls |
|  | superPuls switched off |
|  | Interference |
|  | Temperature error |
|  | Spot welding operating mode |
|  | Material thickness |
|  | Blocked The function selected is not available with the current rights. Check access rights. |
|  | Wire feed speed |
|  | Arc length correction |
|  | Welding power |
| P | Program (P0-P15) P0:-----With decompact machines, welding parameters for program 0 (P0) are configured at the wire feeder control (ex works). To be able to configure these parameters at the Expert 2.0 control, the "P0 configurable by Expert 2.0" parameter has to be set to "Yes" > see 5.4.6 chapter. P1-15 ----Welding parameters can be configured at any control connected to the system. |
|  | Warning Indicates a possible interference in the near future |
|  | Wired local network (LAN) |
|  | Wireless local network (WiFi) |

| Symbol | Description |
|---|--|
|  | User logged in |
|  | Not possible – check priorities |
|  | Xbutton login |
|  | Xbutton logoff |
|  | Arc dynamics |
|  | Xbutton version number not known |
|  | Cancel operation |
|  | Confirm operation |
|  | Wire diameter (welding consumable) |
|  | Menu navigation Skip back to previous menu |
|  | Menu navigation Expand the display contents. |
|  | Save data to USB medium |
|  | Load data from USB medium |
|  | USB data recording |
|  | Screen type 3/4 switching buttons |
|  | Pulse arc welding |
|  | Standard arc welding |
|  | Welding procedure |
|  | Refresh |
|  | After welding, the values used last (hold values) are shown from the main program. |
|  | Information |

4.1.2 Machine display

The machine display shows all the information relevant to the user as text and/or graphics.

4.1.2.1 Actual values, nominal values, hold values

| Parameter | Before welding | During welding | | After welding | |
|--------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| | Nominal value | Actual value | Nominal value | Hold value | Nominal value |
| Welding current | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| Material thickness | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> |
| Wire feed speed | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| Welding voltage | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |

4.1.3 Main screen

The main screen shows all the information relevant for the welding process before, while and after it is carried out. In addition, it shows status information on the machine state. The assignment of the context-dependent push-buttons is also shown on the main screen.

The user can choose between different main screens > see 4.1.3.1 chapter.




Figure 4-2

| Item | Symbol | Description |
|------|--------|--|
| 1 | | Information on the welding task selected JOB number, process etc. |
| 2 | | Display area for welding data Welding current, welding voltage, wire feed speed, material thickness etc. |
| 3 | | Display area for process parameters Operating mode, voltage correction, program, welding method etc. |
| 4 | | Display area for system status Network status, error status etc. |

By pressing push-button A for a prolonged time (on the operating mode main screen) it is possible to directly switch to the program sequence.

4.1.3.1 Main screen variants




Figure 4-3

You can select the required variant (type of main screen) in the Machine configuration (system) menu > see 5.4.6 chapter.

4.1.4 Initial screen

During the start process the control name, machine software version and selected language are shown on the screen.



Figure 4-4

| Item | Symbol | Description |
|------|--------|---|
| 1 | | Machine control name |
| 2 | | Progress bar Shows the load progress during the start process. |
| 3 | | Advanced settings Display and setting of advanced system parameters > see 4.1.4.1 chapter |
| 4 | | Indication of the system language selected The system language can be changed during the start process > see 4.1.4.2 chapter. |
| 5 | | Control software version |

4.1.4.1 Basic settings for operation with two wire feeders (P10)

The setting is available/required in the following cases only:

- the control is integrated in the wire feeder
- the control is integrated in the power source (compact design)

| Menu item/parameter | Value | Comment |
|---------------------|-------|---------|
| DVX (single) | 0 | |
| DVX-Unit 1 (master) | 1 | |
| DVX-Unit 2 (slave) | 2 | |

With single unit operation (P10 = 0) a second wire feeder may not be connected!

- Remove any connections to the second wire feeder

With double unit operation (P10 = 1 or 2) both wire feeders have to be connected and be set up for this operation at the control with different configurations.

- Configure one wire feeder as master (P10 = 1)
- Configure the other wire feeder as slave (P10 = 2)

Access control

If one of the wire feeders in the welding system is equipped with an access control key switch, it has to be configured as master (P10 = 1). With double unit operation, if more than one wire feeder is equipped with an access control key switch, either one can be configured as master. The wire feeder configured as master is active as soon as the welding machine has been switching on. There are no other functional differences between the wire feeders.

4.1.4.2 Change system language

During the start process the user can select or change the system language at the machine control.

- Switch the machine off and on again.
- Press the context-dependent push-button [D] during the start phase (the word MULTIMATRIX is displayed).
- Select the required language by turning the control button.
- Confirm the selected language by pressing the control button (the user can exit the menu by pressing the context-dependent push-button [A] without making any changes).




Figure 4-5

5 Operating the machine control

In general the control is operated with the central control button below the machine display.

Select the required menu item by turning (navigate) and pressing (confirm) the central control button. In addition, the context-dependent push-buttons below the machine display can be used for confirmation.

5.1 Central control button

By turning this button the user can navigate the different menu items and parameters. The inverted display of the selected menu item or parameter indicates the selection.. By pressing the button the menu item or parameter is selected. Repeated turning of the button changes the selected parameter values. Pressing the button again will return the user to the navigation.


By pressing the Arc push-button the user can return to the welding parameter display at any time.

5.2 Direct access keys

Several push-buttons on the right and left of the display can be used to directly access the most important menus.

5.3 Context-dependent push-buttons

The bottom push-buttons are so-called context-dependent operating elements. The selection options of these buttons depend on each screen content.

If the  icon is shown on the display the user can skip back to the previous menu item (often assigned to the [A] push-button).

5.4 Machine configuration (system)

In the System menu the user can set the basic machine configuration.

Enter the menu:




Figure 5-1

5.4.1 Power-saving mode (Standby)

There are three options to activate the power-saving mode:

1. Direct activation by prolonged pressing of the button at the wire feeder control (decompact machines).
2. Direct activation by selecting the "Trigger at once" menu item at the Expert 2.0 machine control.
3. Activation via a configurable parameter in the configuration menu (time-dependent power-saving mode).

When the power-saving mode is active the Expert 2.0 machine control display is dimmed and the wire feeder displays only show the digit in the middle.

Pressing any operating element (e.g. tapping the torch trigger) deactivates the power-saving mode and the machine is ready for welding again.

| Menu item/parameter | Value | Comment |
|------------------------------|-------|---|
| Trigger at once | Yes | When confirmed, the machine enters power-saving mode at once. |
| | No | No change |
| Time automatic [min.] | Off | Function switched off |
| | 5–60 | Time to activation of the power-saving mode in case of inactivity. |
| Log off user in standby mode | Yes | The user will be logged off when the power-saving mode is active. |
| | No | The user will not be logged off when the power-saving mode is active. |

5.4.2 Access permission (Xbutton)

The welding system offers two options to prevent unauthorised access to welding parameters or unintentional reconfiguration.

- 1 Key switch (available depending on machine version). With the key switch in position 1 all functions and parameters can be configured without any restriction. In position 0 certain predefined welding parameters or functions cannot be modified (see relevant documentation).
- 2 Xbutton. With this function, permissions can be assigned to users to access those areas of the machine control defined for them. To do so, the user needs a digital key (Xbutton) to log on to the machine via the Xbutton interface. The key itself is configured by the system user (welding supervisor).

If the Xbutton function is activated, the key switch/key switch function is deactivated.




Figure 5-2

To activate Xbutton rights follow these instructions:

1. Set key switch to position "1".
2. Log on with a Xbutton and administrator rights.
3. Set menu option "Xbutton rights active" to "yes".

By following these instructions you make sure not to inadvertently block your access while not owning an Xbutton with administrator rights.

5.4.2.1 User information

User information such as company ID, user name, group etc. are shown.

5.4.2.2 Activating the Xbutton rights

Menu navigation:

| Menu item/parameter | Value | Comment |
|------------------------------|-------|--|
| Xbutton rights active: | Yes | Access rights active |
| | No | Key switch active |
| Reset Xbutton configuration: | Yes | Company ID, group and access rights when logged off will be reset to the factory settings. Xbutton rights will be deactivated. |
| | No | |

5.4.3 Status information

This menu provides the user with information on current system interferences and warnings..

5.4.3.1 Errors and warnings










Figure 5-3

| Item | Symbol | Description |
|------|---|--|
| 1 | | Error number > see 7.2 chapter |
| 2 | | Error icons  ----- Warning (prior to interference)  ----- Interference (welding process will be stopped)  ----- Specific (e.g. temperature error) |
| 3 | | Long error description |
| 4 |  | Menu navigation Skip back to previous menu |
| 5 |  | Reset message The message can be reset |
| 6 |  | Menu navigation (if available) Scroll to next page or message |
| 7 | | Error name |

5.4.3.2 Running time

| Menu item/parameter | Value | Comment |
|--------------------------|--------|--|
| Duty cycle can be reset: | 0:00 h | Values can be reset by pressing or turning the main control button |
| Arc time can be reset: | 0:00 h | |
| Overall duty cycle: | 0:00 h | |
| Overall arc time: | 0:00 h | |

5.4.3.3 System components

A list of all components available in the system is displayed, along with ID number, software version and name.

5.4.4 System settings

In this area the user can configure advanced system settings.

5.4.4.1 Date

| Menu item/parameter | Value | Comment |
|---------------------|------------|---------|
| Year: | 2014 | |
| Month: | 10 | |
| Day: | 28 | |
| Date format: | DD.MM.YYYY | |
| | YYYY.MM.DD | |

5.4.4.2 Time

| Menu item/parameter | Value | Comment |
|----------------------|--------------|---------|
| Hour: | 0–24 | |
| Minute: | 0–59 | |
| Time zone (UTC +/-): | -12h to +14h | |
| Summer time: | Yes | |
| | No | |
| Time format: | 24 h | |
| | 12 h AM/PM | |

5.4.4.3 Water block

Permanently switching off the water block may damage the welding torch.

| Menu item/parameter | Value | Comment |
|------------------------------------|-----------------|---------|
| Cooling unit postflow time [min.]: | 1–63 | |
| Cooling unit control: | Automatic | |
| | Permanently ON | |
| | Permanently OFF | |

5.4.4.4 Special parameter

The special parameters of the wire feeder control are used to customize the machine function configuration.

The number of selectable special parameters can deviate between the machine controls used in the welding system. A detailed description of the special parameters can be found in the wire feeder operating instructions.

It may be required to restart the machine in order to apply a parameter change.

Systems with two wire feeder controls show the parameters of the active wire feeder only (special parameter U1 or special parameter U2).

| Menu item/parameter | Value | Comment |
|---|-------|---|
| P1: Wire inching ramp time | 1–0 | |
| P2: Block program P0 | 0–1 | |
| P3: U/down torch display mode | 0–1 | |
| P7: Correction operation | 0–1 | |
| P8: Program switching | 0–1 | |
| P9: Tapping start for latched and special latched operation | 0–1 | |
| P11: Special latched tapping time | 0–1 | |
| P12: JOB list switching | 1–2 | |
| P13: JOB range lower limit | 129 | |
| P14: JOB range upper limit | 169 | |
| P16: JOB batch mode | 0–1 | |
| P17: Program selection using torch trigger | 0–1 | |
| P20: Pulse in program A | 1–0 | |
| Reset to factory setting: | No | |
| | Yes | All special parameters are reset to the applicable factory setting. |

5.4.5 Xnet machine

The Xnet machine defines the system component required for operating the Xnet system as part of the Expert 2.0 Net/Gateway to connect to power sources or to record welding data.

5.4.5.1 Clear system memory

Resets the internal system memory used for saving welding and log data and deletes all data.



All welding data recorded so far, which have not been transferred to the Xnet server via flash drive or network connection, will be permanently deleted.

5.4.5.2 Reset to factory settings

All machine configuration data relating to Xnet will be reset to the factory setting. The system memory data will not be affected, i.e. any welding or log data recorded will be saved.

5.4.6 Operating panel settings

| Menu item/parameter | Value | Comment |
|---|----------|---|
| Main screen | 1-2 | |
| Autom. selection of welding power | Off-30 s | |
| Display brightness: | 0-100% | |
| Display contrast: | 0-100% | |
| Display negative: | No | |
| | Yes | |
| Non-latched operation available | No | |
| | Yes | |
| Latched operation available | No | |
| | Yes | |
| Special non-latched operation available | No | |
| | Yes | |
| Spot welding selectable available | No | |
| | Yes | |
| Special latched operation available | No | |
| | Yes | |
| P0 of Expert 2.0 can be changed: | No | |
| | Yes | |
| Average value display for superPuls: | Yes | When superPuls is enabled the welding power is displayed as average value. |
| | No | The welding power is displayed by program A even when superPuls is enabled. |
| Hold function: | On | |
| | Off | |
| Language | German | |
| Reset Expert 2.0 to factory setting | Yes | Only those parameters relevant for Expert 2.0 (e.g. display settings, language and texts) will be reset. System parameters such as Xbutton activation or JOBs are not affected. |
| | No | |

5.4.7 Aligning the cable resistance

The resistance value of cables can either be set directly or it can be aligned using the power source. The factory setting of the power sources is 8 mΩ. This value corresponds to a 5 m earth cable, a 1.5 m intermediate hose package and a 3 m water-cooled welding torch. With other hose package lengths, it is necessary to carry out a +/- voltage correction to optimise welding properties. The voltage correction value can be set close to zero by means of realigning the cable resistance. It is recommended to align the electric cable resistance after replacing accessories such as torches or intermediate hose packages.

In case a second wire feeder is used the (rL2) parameter has to be aligned. For all other configurations it is sufficient to align the (rL1) parameter.

1 Preparation

- Switch off the welding machine.
- Unscrew the gas nozzle from the welding torch.
- Trim the welding wire so that it is flush with the contact tip.
- Retract the welding wire a little (approx. 50 mm) on the wire feeder. There should now be no more welding wire in the contact tip.

2 Configuration

- Switch on the welding machine.
- Press the "System" push-button.
- Select the "Cable resistance alignment" parameter using the main control button. Parameter RL1 must be aligned for all machine combinations. In case of welding systems with a second power circuit – if two wire feeders are to be operated from a single power source, for example – a second alignment with parameter RL2 must be performed. To activate the required wire feeder for measurement briefly activate (tap) the torch trigger of this machine.

3 Alignment/Measurement

- Press the "D" push-button.
- Applying slight pressure, put the welding torch with the contact tip against a clean, purged location on the workpiece and then press the torch trigger for approx. 2 seconds. A short-circuit current will flow briefly, which is used to determine and display the cable resistance. The value can be between 0 mΩ and 40 mΩ. The new value is immediately saved without requiring further confirmation. If no value is shown on the display, then measurement failed. The measurement must be repeated.
- Press the "A" push-button once the measurement has been successful.

4 Restoring welding standby mode

- Switch off the welding machine.
- Screw the gas nozzle onto the welding torch.
- Switch on the welding machine
- Insert the welding wire.




Figure 5-4

5.5 Offline data transfer (USB)



You may only use this USB interface to exchange data with a USB flash memory. You must not connect any other USB devices such as keyboards, hard disks, mobile telephones, cameras or other devices so as to avoid any damage to the machine. The interface does not provide any load functions either.

Using the USB interface, data can be transferred between the machine control and a USB storage medium.




Figure 5-5

5.5.1 Save JOB(s)

Saving a single (JOB) or a range of welding tasks (JOB)s (from-to) from the welding machine to the storage media (USB).

5.5.2 Load JOB(s)

Loading a single JOB or a range of welding tasks (JOB)s (from-to) from the storage media (USB) to the welding machine.

5.5.3 Save configuration

5.5.3.1 Master configuration

Core data for network communication (independent of machine).

5.5.3.2 Individual configuration

Machine-related configuration data, matching the current power source only.

5.5.4 Load configuration

5.5.4.1 Master configuration

Core data for network communication (independent of machine).

5.5.4.2 Individual configuration

Machine-related configuration data, matching the current power source only.

5.5.5 Load languages and texts

Load a language and text package from the storage medium (USB) to the welding machine.

5.5.6 Record on USB drive


You can record welding data on a storage medium and read or analyse them using the Xnet quality management software when required. For machine variants with network capability (LG/WLG) only!

5.5.6.1 Register USB drive

To identify and allocate the welding data between power source and storage medium the storage medium has to be registered once. This is done by selecting the menu option "Register USB drive" or by starting a data recording process. Successful registration is indicated by a checkmark next to the relevant menu option.

If the storage medium is registered and connected when the power source is being switched on, recording of the welding data starts automatically.

5.5.6.2 Start recording

After confirming the start of data recording the storage medium will be registered (if not registered yet). Data recording starts and is indicated at the main screen by a slow flashing of the  icon.

5.5.6.3 Stop recording

To avoid data loss, finish the recording with this menu option before removing the USB drive or switching off the machine.



Welding data must be imported into the Xnet quality management software using the XWDImport software. This software is an integral part of the Xnet installation.

5.6 Welding task administration (Menu)

In this menu the user can carry out all welding task (JOB) organisation operations.

This machine series offers user-friendly operation and a multitude of features.

- Various welding tasks (JOBS) consisting of welding procedure, material type, wire diameter and shielding gas type have been predefined > see 9.1 chapter.
- The system calculates the required process parameters depending on the operating point specified (one-knob operation via wire feed speed rotary transducer).
- You can adjust additional parameters at the machine control or using the PC300.NET welding parameter software, if required.

Enter the menu:




Figure 5-6

5.6.1 JOB selection (material/wire/gas)

The welding task (JOB) can be set in two ways:

- a) Enter the relevant JOB number. Each welding task has a unique, three-digit JOB number (for predefined JOBS > see 9.1 chapter see the JOB list in the annex or the sticker on the machine).
- b) Enter the basic welding parameters: welding procedure, material type, wire diameter and shielding gas type.

5.6.2 JOB manager

5.6.2.1 Copy JOB to number

Copy JOB to a number of the definable range (129–169).

5.6.2.2 Reset current JOB

Reset all parameters of the selected JOB to the factory setting

5.6.2.3 Reset all JOBS

Reset all JOBS to the factory setting, except JOBS in the definable range (129–169).

5.6.3 Program sequence



The setting range for the parameter values are summarised in the parameter overview section > see 8.1 chapter.

In the program sequence, you can select welding parameters and set their values. The number of parameters shown depends on the selected operating mode.

In addition, the user can access advanced settings and the setup mode.




Figure 5-7

| Item | Symbol | Description |
|------|--------|--|
| 1 | ▲ | Parameter position Displays the currently selected welding parameters in the functional sequence |
| 2 | ⚙️ | Advanced settings Display and setting of advanced process parameters |
| 3 | 🔧/🔩 | Setup mode > see 5.6.4 chapter |
| 4 | | Operating mode setting |

5.6.3.1 MIG/MAG welding

In every JOB, separate settings can be made for the ignition program, reduced main program and end program as to whether or not to alternate with the pulse process.

These properties are stored on the welding machine with the JOB. This means that in the factory settings, the pulse process is active during the end program in all forceArc JOBS.




Figure 5-8



P_{START} , P_B and P_{END} are set as relative programs ex factory. They relate to percentages of the wire feed value of the main program P_A . These programs can also be configured using absolute values, if desired (see Absolute value set point). > see 5.6.6 chapter.

| Menu item/parameter | Program | Comment |
|---------------------|-------------|---|
| Gas pre-flow time | | |
| Gas nominal value | | GFE option/variant (electronic gas volume control) required |
| WF relative | P_{START} | Wire feed speed, relative |
| Duration | | Duration (start program) |
| U correction | | Arc length correction |
| Slope time | | Slope duration from P_{START} to P_A |
| WF (/min.) | P_A | Wire feed speed, absolute |
| U correction | | Arc length correction |
| Duration | | Duration (spot time and superPuls time) |
| Slope time | | Slope duration from P_A to P_B |
| WF relative | P_B | Wire feed speed, relative |
| Duration | | Duration (reduced main program) |
| U correction | | Arc length correction, relative |
| Slope time | | Slope duration from P_B to P_A |
| Slope time | | Slope duration from P_B to P_{END} |
| WF relative | P_{END} | Wire feed speed, relative |
| Duration | | Duration (end program) |
| U correction | | Arc length correction, relative |
| Wire burn-back | | |
| Gas post-flow time | | |

5.6.3.2 Advanced settings

| Menu item/parameter | Value | Comment |
|----------------------------------|---------------|---|
| Process switching | Off | |
| | On | |
| Start program pulsing | Off | |
| | On | |
| End program pulsing | Off | |
| | On | |
| Wire retraction ignition | Off | |
| | Lift arc (PP) | |
| | Lift arc | |
| End pulse duration | 0.0–20 ms | |
| U correction limit | 0.0–9.9 V | Applies with correction operation enabled |
| Wire correction limit | 0–30% | |
| N cycle program limit | Off | |
| | 2–9 | |
| Slope between programs (/100 ms) | Off | |
| | 0.1–2.0 m/min | |
| waveArc | Off | |
| | On | |

5.6.3.3 Overview of the welding parameter switching options

Different welding tasks or positions on a workpiece demand various welding performances (operating points) or welding programs. The following parameters are stored in each of the up to 16 programs:

- Operating mode
- Welding type
- superPuls (ON/OFF)
- Wire feed speed (DV2)
- Voltage correction (U2)
- Dynamics (DYN2)

The user can change the main program welding parameters using the following components.

| | Program switching | JOB switching | Program | Operating mode | Welding process | superPuls | Wire speed | Voltage correction | Dynamics |
|-------------------------------------|-------------------|---------------|---------|----------------|-----------------|-----------|-------------------|--------------------|----------|
| M3.7x Wire feeder control | Yes | Yes | P0 | Yes | | | Yes | Yes | |
| | | | P1...15 | | | | Yes | | |
| R20 Remote control | Yes | No | P0 | No | | | Yes | No | |
| | | | P1...9 | | | | Yes ¹⁾ | | |
| R40 Remote control | Yes | No | P0 | No | Yes | Yes | | No | |
| | | | | | | No | | | |
| R50 Remote control | Yes | No | P0 | Yes | | | Yes | | |
| | | | P1...15 | | | | | | |
| PC 300.NET Software | No | No | P0 | Yes | | | No | | |
| | | | P1...15 | | | | | | |
| Up/Down Welding torch | Yes | No | P0 | No | | | Yes | No | |
| | | | P1...9 | | | | No | | |
| 2 Up/Down Welding torch | Yes | No | P0 | No | | | Yes | | No |
| | | | P1...15 | | | | No | | |
| PC 1 Welding torch | Yes | No | P0 | No | | | Yes | No | |
| | | | P1...15 | | | | No | | |
| PC 2 Welding torch | Yes | Yes | P0 | No | | | Yes | | No |
| | | | P1...15 | | | | No | | |

1) in case of correction mode, refer to Special parameters "P7 – correction mode, limit value setting"

Example 1: Welding workpieces with different sheet metal thicknesses (non-latched)




Figure 5-9

Example 2: Welding different positions on a workpiece (latched)




Figure 5-10

Example 3: Aluminium welding of different sheet metal thicknesses (non-latched or latched special)




Figure 5-11



Up to 16 programs (P_{A0} to P_{A15}) can be defined.

An operating point (wire speed, arc length correction, dynamics/choke effect) can be defined permanently in each program.

Program P_0 is an exception: the settings for operating points are made manually here.

Changes to the welding parameters are saved immediately!

5.6.3.4 TIG welding




Figure 5-12

| Menu item/parameter | Program | Comment |
|---------------------|--------------------|---|
| Gas pre-flow time | | |
| Gas nominal value | | GFE option/variant (electronic gas volume control) required |
| Current | P _{START} | Ignition current |
| Duration | | Duration (start program) |
| Slope time | | Slope duration from P _{START} to P _A |
| Current | P _A | Welding current, absolute |
| Duration | | Pulse time (superPuls) |
| Slope time | | Slope duration from P _A to P _B |
| Current | P _B | Welding current |
| Duration | | Pulse pause time (superPuls) |
| Slope time | | Slope duration from P _B to P _A |
| Slope time | | Slope duration from P _A to P _{END} |
| Current | P _{END} | Welding current |
| Duration | | |
| Gas post-flow time | | |

5.6.3.5 MMA welding




Figure 5-13

| Menu item/parameter | Comment |
|---------------------|-------------------|
| Current | Hot start current |
| Duration | Hot start time |
| Current | Main current |

 **The hotstart current is a percentage based on the welding current selected.**

5.6.4 Setup mode







Figure 5-14

| Item | Symbol | Description |
|------|--|--|
| 1 |  | Wire return Results in reverse inching of the wire. Pressing the push-button longer will increase the wire reversing speed. |
| 2 |  | Wire inching The wire is inched into the hose package. Pressing the push-button longer will increase the wire inching speed. |
| 3 |  | Push-button gas test / rinse hose package |

All functions run without current (set-up phase). This provides a high degree of safety for the welder, since the arc cannot be inadvertently ignited. The following parameters can be monitored during the wire configuration:

| Menu item/parameter | Value | Comment |
|---------------------|-----------|---|
| WF nominal value | 0.0 m/min | only if the control is integrated in the wire feeder |
| WF actual value | 0.0 m/min | |
| Motor current | 0.0 A | |
| Gas nominal value | 0.0 l/min | GFE option/variant (electronic gas volume control) required |
| Gas flow | 0.0 l/min | |

5.6.5 Welding data monitoring

The welding data monitoring parameters are used by an external monitoring device.

| Menu item/parameter | Value | Comment |
|---------------------------------|-------------|------------------------------------|
| Voltage tolerance | 0–100% | |
| Current tolerance | 0–100% | |
| Tolerance response time | 0.00–20.0 s | For voltage and current tolerance |
| WF tolerance: | 0–100% | |
| Max. permissible motor current: | 0.0–5.0 A | |
| Tolerance response time | 0.00–20.0 s | For WF tolerance and motor current |

5.6.6 JOB display setting

| Menu item/parameter | Value | Comment |
|---------------------------|-------------|---|
| Text for material: | Standard | |
| | Alternative | |
| Diameter unit: | mm | |
| | inch | |
| Text for gas: | Standard | |
| | Alternative | |
| Absolute value set point: | Yes | Ignition current, secondary current and end current are set and displayed as absolute values |
| | No | Ignition current, secondary current and end current are defined and displayed as a percentage of program A (ex works) |

5.7 Change welding procedure (Arc)

In this menu the user can change the welding procedure based on the preselected material, wire and gas (change of process based on welding task).

For changing the welding task (JOB) > see 5.6 chapter

Enter the menu:




Figure 5-15

5.8 Online data transfer (network)



For machine variants with network capability (LG/WLG) only!

The network is used to transfer welding data from manual, automated and robot welding machines. It can include as many welding machines and computers as require and the collected data can be retrieved from one or several server PCs.

The Xnet software allows the user to monitor all welding parameters in real time and/or to subsequently analyse the saved welding data. The results can be used for process optimisation, welding calculations or checking welding wire batches.

Depending on the welding machine the data are transferred to the server via LAN/WiFi and can then be accessed in a browser window. The user interface and web-based design of the software offer the possibility to analyse and monitor the welding data via a tablet PC.

5.8.1 Wired local network (LAN)

LAN status:

| Status description | Status display Expert 2.0 | LED LAN status (LAN/LAN gateway) |
|--|---|--|
| No physical connection to a network | LAN icon deactivated | Off |
| Connection to the network, the machine has been configured, no data transfer | LAN icon activated | Green, permanently illuminated |
| Connection to the network, the machine has been configured and transfers data | LAN icon flashing | Green, flashes with 1 Hz |
| Connection to the network, the machine has been configured and tries to connect to the data server | LAN icon flashing in the specified rhythm | Green, flashing in the following rhythm: 1 s off, 0.2 s on |

5.8.2 Wireless local network (WiFi)

WiFi status:

| Status description | Status display Expert 2.0 | LED WiFi status (LAN/WiFi gateway) |
|--|---|--|
| No physical connection to a network | WiFi icon deactivated | Off |
| Connection to a network, no data transfer | WiFi icon activated | Permanently on |
| Connection to a network, transferring data | WiFi icon flashing | Flashing with 1 Hz |
| Connection to the network, the machine has been configured and tries to connect to the data server | LAN icon flashing in the specified rhythm | Green, flashing in the following rhythm: 1 s off, 0.2 s on |

6 Welding procedure

The welding task is selected in the JOB selection menu (material/wire/gas) > see 5.6.1 chapter.

The basic settings of the relevant welding procedure, such as operating mode or arc length correction, can be selected on the main screen on the process parameter panel > see 4.1.3 chapter.

The program sequence settings are set in the program sequence menu > see 5.6.3 chapter.

6.1 MIG/MAG welding

6.1.1 Operating modes



There are optimum pre-sets for welding parameters such as gas pre-flow and burn back, etc. for numerous applications (although these can also be changed if required).

6.1.1.1 Explanation of signs and functions

| Symbol | Meaning |
|---|---|
|  | Press torch trigger |
|  | Release torch trigger |
|  | Tap torch trigger (press briefly and release) |
|  | Shielding gas flowing |
|  | Welding output |
|  | Wire electrode is being conveyed |
|  | Wire creep |
|  | Wire burn-back |
|  | Gas pre-flows |
|  | Gas post-flows |
|  | Non-latched |
|  | Special, non-latched |
|  | Latched |
|  | Special, latched |
| t | Time |
| P _{START} | Ignition program |
| P _A | Main program |
| P _B | Reduced main program |
| P _{END} | End program |
| t ₂ | Spot time |




Figure 6-1

Step 1

- Press and hold torch trigger.
- Shielding gas is expelled (gas pre-flows).
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows.
- Change over to pre-selected wire speed.

Step 2

- Release torch trigger.
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.

Non-latched operation with superpulse




Figure 6-2

Step 1

- Press and hold torch trigger.
- Shielding gas is expelled (gas pre-flows).
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows.
- Start the super pulse function beginning with main program P_A :
The welding parameters change at the specified times between main program P_A and the reduced main program P_B .

Step 2

- Release torch trigger.
- Super pulse function is ended.
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.




Figure 6-3

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START} for the time t_{start})
- Slope to main program P_A .

Step 2

- Release torch trigger
- Slope to end program P_{END} for the time t_{end} .
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.




Figure 6-4

 **The ignition time t_{start} must be added to the spot time t_2 .**

1st cycle

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed"
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START} , spot time starts)
- Slope to main program P_A
- After the set spot time elapses, slope goes to end program P_{END} .
- Wire feed motor stop welding.
- Arc is extinguished after the pre-selected wire burn-back time elapses
- Gas post-flow time elapses.

2nd cycle

- Release torch trigger

Releasing the torch trigger (step 2) interrupts the welding process even if the spot time has not yet elapsed (slope to end program P_{END}).




Figure 6-5

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START} for the time t_{start}).
- Slope on main program P_A .
- Start the super pulse function beginning with main program P_A :
The welding parameters change at the specified times between main program P_A and the reduced main program P_B .

Step 2

- Release torch trigger
- Super pulse function is ended.
- Slope to end program P_{END} for the time t_{end} .
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.




Figure 6-6

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows.
- Change over to pre-selected WF speed (main program P_A).

Step 2

- Release torch trigger (no effect)

Step 3

- Press torch trigger (no effect)

Step 4

- Release torch trigger
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.

Latched mode with superpulse




Figure 6-7

Step 1:

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows.
- Start the super pulse function beginning with main program P_A.
The welding parameters change at the specified times between main program P_A and the reduced main program P_B.

Step 2:

- Release torch trigger (no effect)

Step 3:

- Press torch trigger (no effect)

Step 4:

- Release torch trigger
- Super pulse function is ended.
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.

Latched with changing welding method (process switching)



Only for machines with pulsed arc welding type, see the Area of application table > see 3.2 chapter.




Figure 6-8

1st cycle:

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed"
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows
- Start the process alternation starting with process P_A :
The welding processes alternate between the process P_A stored in the JOB and the opposite process P_B at the specified times (t_2 and t_3)

If a standard process is stored in the JOB, this means that there is a permanent alternation between the processes, starting with the standard process and followed by the pulse process. The same applies if the situation is reversed.

2nd cycle:

- Release torch trigger (no effect)

3rd cycle:

- Press torch trigger (no effect)

4th cycle:

- Release torch trigger
- Super pulse function is ended
- WF motor stops
- Arc is extinguished after the pre-selected wire burn-back time elapses
- Gas post-flow time elapses



This function can be activated using the PC300.NET software. Refer to the software operating instructions.

Latched special




Figure 6-9

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START})

Step 2

- Release torch trigger
- Slope to main program P_A .

The slope on main program P_A is given at the earliest after the set time t_{START} elapses and at the latest when the torch trigger is released.

Tapping¹⁾ can be used to change over to the reduced main program P_B .

Repeated tapping will switch back to the main program P_A .

Step 3

- Press and hold torch trigger
- Slope to end program P_{END} .

Step 4

- Release torch trigger
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.



¹⁾ Prevent tapping (brief press and release within 0.3 seconds)

If the welding current is to be prevented from switching over to the reduced main program P_B by tapping, the parameter value for WF3 needs to be set to 100% ($P_A = P_B$) in the program sequence.

Special latched with changing welding method by tapping (process switching)



Only for machines with pulsed arc welding type, see the Area of application table > see 3.2 chapter.




Figure 6-10

1st cycle

- Press and hold torch trigger.
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed"
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START})

2nd cycle

- Release torch trigger
- Slope on main program P_A

The slope on main program P_A is given at the earliest after the set time t_{START} elapses and at the latest when the torch trigger is released.

Tapping (pressing the torch trigger for less than 0.3 sec.) changes over the welding process (P_B).

If a standard process has been defined in the main program, tapping changes to the pulse process, and tapping again will return to the standard process, etc.

3rd cycle

- Press and hold torch trigger
- Slope to end program P_{END}

4th cycle

- Release torch trigger
- WF motor stops
- Arc is extinguished after the pre-selected wire burn-back time elapses
- Gas post-flow time elapses



This function can be activated using the PC300.NET software. Refer to the software operating instructions.

Special latched with changing welding method (process switching)



Only for machines with pulsed arc welding type, see the Area of application table > see 3.2 chapter.




Figure 6-11

1st cycle

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed"
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START} for the time t_{start})

2nd cycle

- Release torch trigger
- Slope on main program P_A
- Start the process alternation starting with process P_A :
The welding processes alternate between the process P_A stored in the JOB and the opposite process P_B at the specified times (t_2 and t_3)

If a standard process is stored in the JOB, this means that there is a permanent alternation between the processes, starting with the standard process and followed by the pulse process. The same applies if the situation is reversed.

3rd cycle

- Press the torch trigger
- Super pulse function is ended
- Slope in the end program P_{END} for the time t_{end}

4th cycle

- Release torch trigger
- WF motor stops
- Arc is extinguished after the pre-selected wire burn-back time elapses
- Gas post-flow time elapses



This function can be activated using the PC300.NET software. Refer to the software operating instructions.

Special, latched with superpulse




Figure 6-12

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at “creep speed”.
- Arc ignites after the wire electrode makes contact with the workpiece, welding current is flowing (start program P_{START} for the time t_{start}).

Step 2

- Release torch trigger
- Slope on main program P_A .
- Start the super pulse function beginning with main program P_A :
The welding parameters change at the specified times between main program P_A and the reduced main program P_B .

Step 3

- Press the torch trigger.
- Super pulse function is ended.
- Slope in the end program P_{END} for the time t_{end} .

Step 4

- Release torch trigger
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.

6.1.1.2 MIG/MAG automatic cut-out



The welding machine ends the ignition process or the welding process with an

- **ignition fault (no welding current flows within 5 s after the start signal)**
- **arc interruption (arc is interrupted for longer than 5 s)**

6.1.2 coldArc / coldArc puls

Heat-reduced, low-spatter short arc for high dimensional stability welding and brazing, plus root welding with excellent gap bridging capabilities.



Figure 6-13

After selecting the coldArc process > see 5.6.1 chapter the following properties are available:

- Less distortion and reduced discolouration thanks to minimised heat input
- Considerably reduced spatter thanks to virtually power-free material transfer
- Easy welding of root passes in all panel thicknesses and in all positions
- Perfect gap bridging even with inconsistent gap widths
- Unalloyed, low-alloy and high-alloy steels and also dissimilar joints of even the thinnest metal sheets
- Brazing of CrNi sheets with CuAl8/AlBz8
- Brazing and welding of coated metal sheets, e.g. with CuSi, AlSi and Zn
- Manual and automated applications

| coldArc welding to: | | Wire Ø (mm) | | | | | | | | | | | |
|---------------------|-----------|-------------|-----|-----|------|-----|-----|-----|-----|-----|-----|-----|-----|
| | | 0.8 | | 0.9 | | 1 | | 1.2 | | 1.6 | | | |
| Material | Gas | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ | | |
| CrNi | Ar 91–99% | - | - | - | - | 51 | 7.0 | 52 | 6.0 | - | - | | |
| AlMg | Ar 100% | - | - | - | - | 55 | 8.0 | 56 | 8.0 | - | - | | |
| AlSi | Ar 100% | - | - | - | - | 59 | 8.0 | 60 | 6.0 | - | - | | |
| AL99 | Ar 100% | - | - | - | - | 63 | 8.0 | 64 | 6.0 | - | - | | |
| Steel | Ar 91–99% | - | - | - | - | - | - | - | - | - | - | | |
| | Ar 80–90% | 191 | 7.0 | 192 | 6.0 | 193 | 6.0 | 194 | 5.0 | 195 | 5.0 | | |
| | CO2 | 182 | 7.0 | 183 | 6.0 | 184 | 6.0 | 185 | 5.0 | 186 | 5.0 | | |
| coldArc brazing to: | | Wire Ø (mm) | | | | | | | | | | | |
| | | 0.6 | | 0.8 | | 0.9 | | 1 | | 1.2 | | 1.6 | |
| Material | Gas | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ | JOB | ⊗ |
| CuSi | Ar 100% | - | - | 66 | 10.0 | - | - | 67 | 8.0 | 68 | 6.0 | 69 | 6.0 |
| CuAl | Ar 100% | - | - | 70 | 7.0 | - | - | 71 | 6.0 | 72 | 6.0 | 73 | 7.0 |
| AlSi | Ar 100% | - | - | 196 | 8.0 | - | - | 197 | 8.0 | 198 | 8.0 | 199 | 8.0 |
| Zn | Ar 100% | - | - | 200 | 6.0 | - | - | 201 | 6.0 | 202 | 6.0 | 203 | 6.0 |

You can make use of these properties after selecting the coldArc process (see the "Selecting a MIG/MAG welding task" chapter).

With coldArc welding, it is important to ensure good quality wire feeding because of the welding filler materials being used!

- Equip the welding torch and torch hose package to suit the task! (and the operating instructions for the welding torch.)



This function can only be enabled with the PC300.NET software.
(See operating instructions for the software)

6.1.3 forceArc / forceArc puls

Low-heat, directionally stable and powerful high-performance arc with deep fusion penetration for the upper power range Unalloyed, low-alloy and high-alloy steels as well as high-tensile fine-grained steels.




Figure 6-14

- Smaller included angle due to deep penetration and directionally stable arc
- Excellent root and sidewall fusion
- Secure welding also with very long stick-outs
- Reduced undercuts
- Un-, low- and high-alloyed steels as well as high-tensile fine-grained building steels
- Manual and automated applications

| forceArc welding from: | | Wire Ø (mm) | | | | | | | |
|------------------------|-----------|-------------|------|-----|------|-----|------|-----|-----|
| | | 0.8 | | 1 | | 1.2 | | 1.6 | |
| Material | Gas | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø |
| Steel | Ar 91–99% | 190 | 17.0 | 254 | 12.0 | 255 | 9.5 | 256 | 7.0 |
| | Ar 80–90% | 189 | 17.0 | 179 | 12.0 | 180 | 9.5 | 181 | 6.0 |
| CrNi | Ar 91–99% | - | - | 251 | 12.0 | 252 | 12.0 | 253 | 6.0 |

You can make use of these properties after selecting the forceArc process > see 5.6.1 chapter.

As with pulse arc welding, it is important to make sure of a good welding current connection.

- Keep welding current cables as short as possible and ensure that cable cross-sections are adequate!
- Fully unroll welding current cables, torch hose packages and, if applicable, intermediate hose packages. Avoid loops!
- Use welding torches, preferably water-cooled, that are suitable for the higher power range.
- Use welding wire with adequate copper coating when welding steel. The wire spool should have layer spooling.



Unstable arc!

Welding current cables that are not fully unrolled can cause faults in the arc (flickering).

- **Fully unroll welding current cables, torch hose packages and, if applicable, intermediate hose packages. Avoid loops!**

6.1.4 rootArc/rootArc puls

Short arc with perfect weld modelling capabilities for effortless gap bridging, especially for positional welding




Figure 6-15

- Reduced spatter compared to standard short arc
- Good root formation and secure sidewall fusion
- Un-alloyed and low-alloy steels
- Manual and automated applications

| rootArc welding up to: | | Wire Ø (mm) | | | | | | | | | | | |
|------------------------|-----------------|-------------|---|-----|---|-----|---|-----|-----|-----|-----|-----|---|
| | | 0.6 | | 0.8 | | 0.9 | | 1 | | 1.2 | | 1.6 | |
| Material | Gas | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø |
| Steel | CO ₂ | - | - | - | - | - | - | 204 | 7.0 | 205 | 5.0 | - | - |
| | Ar 80–90% | - | - | - | - | - | - | 206 | 8.0 | 207 | 6.0 | - | - |



Unstable arc!

Welding current cables that are not fully unrolled can cause faults in the arc (flickering).

- Fully unroll welding current cables, torch hose packages and, if applicable, intermediate hose packages. Avoid loops!

6.1.5 pipeSolution

Reduced-energy MAG welding. X-ray-proof welding of pipelines and pipework without lack of fusion. Root pass and fill and final pass with or without air gap. Low- and high-alloy steels with solid wires.




Figure 6-16

- Root welding for metal sheets and pipes in all positions
- Unalloyed and low-alloy steels as well as high-tensile fine-grained steels
- Manual and automated applications

| pipeSolution welding to: | | Wire Ø (mm) | | | | | | | | | | | |
|--------------------------|-----------------|-------------|---|-----|---|-----|---|-----|-----|-----|-----|-----|---|
| | | 0.6 | | 0.8 | | 0.9 | | 1 | | 1.2 | | 1.6 | |
| Material | Gas | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø | JOB | Ø |
| Steel | CO ₂ | x | x | x | x | x | x | 171 | 6.0 | 172 | 5.0 | x | x |
| | Ar 80–90% | x | x | x | x | x | x | 173 | 6.0 | 174 | 5.0 | x | x |

6.1.6 Standard MIG/MAG torch

The MIG welding torch trigger is essentially used to start and stop the welding process.

| Operating elements | Functions |
|---|--|
|  Torch trigger | <ul style="list-style-type: none"> Start/stop welding |

Other functions are also possible by tapping the torch trigger, depending on the machine type and control configuration > see 5.4.4.4 chapter:

- Change over between welding programs (P8).
- Program selection before starting welding (P17).
- Change over between pulse and standard welding in the special latched operating mode.
- Switching between wire feed units in dual operation mode (P10).

6.1.7 MIG/MAG special-torches

Function specifications and more indepth information can be found in the operating manual for the relevant welding torch!

6.1.7.1 Program and up/down operation







Figure 6-17

| Item | Symbol | Description |
|------|---|---|
| 1 |  | Welding torch function changeover switch (special welding torch required)  Up / Down ---- Welding power infinitely adjustable  Programm --- Change over programs or JOBS |

6.1.7.2 Switching between Push/Pull and intermediate drive

WARNING



Do not carry out any unauthorised repairs or modifications!

To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!

The warranty becomes null and void in the event of unauthorised interference.

- Appoint only skilled persons for repair work (trained service personnel)!



Test!

Before re-commissioning, it is essential that an "inspection and test during operation" is carried out conforming to IEC / DIN EN 60974-4 "Arc welding devices - inspection and testing during operation"!

- ***For detailed instructions, please see the standard operating instructions for the welding machine.***











The plugs are located directly on the M3.7x printed circuit board.

| Plug | Function |
|--------|--|
| on X24 | Operation with Push/Pull welding torch (factory setting) |
| on X23 | Operation with intermediate drive |

6.2 TIG welding

6.2.1 Function sequences/operating modes

6.2.1.1 Explanation of signs and functions

| Symbol | Meaning |
|---|---|
|  | Press torch trigger |
|  | Release torch trigger |
|  | Tap torch trigger (press briefly and release) |
|  | Shielding gas flowing |
| I | Welding output |
|  | Gas pre-flows |
|  | Gas post-flows |
|  | Non-latched |
|  | Special, non-latched |
|  | Latched |
|  | Special, latched |
| t | Time |
| P _{START} | Ignition program |
| P _A | Main program |
| P _B | Reduced main program |
| P _{END} | End program |
| tS1 | Slope duration from PSTART to PA |

Non-latched mode




Figure 6-18

Selection

- Select non-latched operating mode .

Step 1

- Press and hold torch trigger.
- Shielding gas is expelled (gas pre-flows).

The arc is ignited using liftarc.

- Welding current flows with pre-selected setting.

Step 2

- Release torch trigger.
- Arc is extinguished.
- Gas post-flow time elapses.

Special, non-latched




Figure 6-19

Selection

- Select non-latched special mode .

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)

The arc is ignited using liftarc.

- Welding gas flows with pre-selected setting in start program "P_START".
- After the "tstart" ignition current time elapses, the welding current rises with the set upslope time "tS1" to the main program "P_A".

Step 2

- Release torch trigger.
- The welding current reduces with the downslope time "tSe" to the end program "P_END".
- After the end current time "end" elapses, the arc will extinguish.
- Gas post-flow time elapses.





Figure 6-20

Selection

- Select latched operating mode .

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)

The arc is ignited using liftarc.

- Welding current flows with pre-selected setting.

Step 2

- Release torch trigger (no effect)

Step 3

- Press torch trigger (no effect)

Step 4

- Release torch trigger
- Arc is extinguished.
- Gas post-flow time elapses.




Figure 6-21

Selection

- Select latched special mode

Step 1

- Press and hold torch trigger.
- Shielding gas is expelled (gas pre-flows).

The arc is ignited using liftarc.

- Welding gas flows at pre-selected setting in start program "P_{START}".

Step 2

- Release torch trigger.
- Slope on main program "P_A".

The slope on main program P_A is given at the earliest after the set time t_{START} elapses and at the latest when the torch trigger is released.

Tapping can be used to switch to the reduced main program "P_B". Repeated tapping will switch back to the main program "P_A".

Step 3

- Press the torch trigger.
- Slope to end program "P_{END}".

Step 4

- Release torch trigger.
- Arc is extinguished.
- Gas post-flow time elapses.

6.2.2 TIG automatic cut-out



The welding machine ends the ignition process or the welding process with an

- **ignition fault** (no welding current flows within 5 s after the start signal)
- **arc interruption** (arc is interrupted for longer than 5 s)

6.2.3 TIG arc ignition

6.2.3.1 Liftarc




Figure 6-22

The arc is ignited on contact with the workpiece:

- Carefully place the torch gas nozzle and tungsten electrode tip onto the workpiece and press the torch trigger (liftarc current flowing, regardless of the main current set).
- Incline the torch over the torch gas nozzle to produce a gap of approx. 2-3 mm between the electrode tip and the workpiece. The arc ignites and the welding current is increased, depending on the operating mode set, to the ignition or main current set.
- Lift off the torch and swivel to the normal position.

Ending the welding process: Release or press the torch trigger depending on the operating mode selected.

6.3 MMA welding

6.3.1 Hotstart

The hotstart device improves the ignition of the stick electrodes using an increased ignition current.

- a) = Hotstart time
- b) = Hotstart current
- I = Welding current
- t = Time





Figure 6-23

For hotstart parameter settings, > see 8.1 chapter

6.3.2 Antistick



Anti-stick prevents the electrode from annealing.

If the electrode sticks in spite of the Arcforce device, the machine automatically switches over to the minimum current within about 1 second to prevent the electrode from overheating. Check the welding current setting and correct according to the welding task!

Figure 6-24

6.3.3 Air arc gouging

During gouging, an arc burns between a carbon electrode and the workpiece, heating the workpiece until it is molten. At the same time, the molten metal is blown out with compressed air. Special electrode holders with a compressed-air connection and carbon electrodes are required for gouging.


7 Rectifying faults

All products are subject to rigorous production checks and final checks. If, despite this, something fails to work at any time, please check the product using the following flowchart. If none of the fault rectification procedures described leads to the correct functioning of the product, please inform your authorised dealer.

7.1 Display machine control software version

Identifying the machine software is key to quick troubleshooting by the authorised service technician. The version number is shown on the initial screen of the machine control for about 5 seconds (switch the machine off and on again) > see 4.1.4 chapter.

7.2 Error messages (power source)

 **A welding machine error is indicated by an error code being displayed (see table) on the display on the machine control.**

In the event of a machine error, the power unit is shut down.

 **The display of possible error numbers depends on the machine version (interfaces/functions).**





- Document machine errors and inform service staff as necessary.
- If multiple errors occur, these are displayed in succession.

| Error (Err) | Category | | | Possible cause | Remedy |
|-------------|----------|----|----|--|--|
| | a) | b) | c) | | |
| 1 | - | - | x | Mains overvoltage | Check the mains voltages and compare with the welding machine connection voltages |
| 2 | - | - | x | Mains undervoltage | |
| 3 | x | - | - | Welding machine excess temperature | Allow the machine to cool down (mains switch to "1") |
| 4 | x | x | - | Low coolant level | Top up the coolant Leak in the coolant circuit > repair the leak and top up the coolant Coolant pump is not working > check excess current trigger on air cooling unit |
| 5 | x | - | - | Wire feeder/tachometer error | Check the wire feeder Speedometer is not emitting a signal, M3.51 defective > inform Service. |
| 6 | x | - | - | Shielding gas error | Check shielding gas supply (for machines with shielding gas monitoring) |
| 7 | - | - | x | Secondary overvoltage | Inverter error > inform Service |
| 8 | - | - | x | Earth fault between welding wire and earth line | Separate the connection between welding wire and casing or an earthed object |
| 9 | x | - | - | Fast cut-out Triggered by BUSINT X11 or RINT X12 | Rectify error on robot |
| 10 | - | x | - | Arc interruption Triggered by BUSINT X11 or RINT X12 | Check wire feeding |
| 11 | - | x | - | Ignition error after 5 s Triggered by BUSINT X11 or RINT X12 | Check wire feeding |
| 13 | x | - | - | Emergency stop deactivation | Check the emergency stop circuit at the interface for automated welding |
| 14 | - | x | - | Wire feeder not detected. Control cable not connected. | Check cable connections. |
| | | | | Incorrect ID numbers assigned during operation with multiple wire feeders. | Check ID number assignation > see 4.1.4.1 chapter |

| Error (Err) | Category | | | Possible cause | Remedy |
|-------------|----------|----|----|---|---|
| | a) | b) | c) | | |
| 15 | - | x | - | Wire feeder 2 not detected. Control cable not connected. | Check cable connections. |
| 16 | - | - | x | VRD (open circuit voltage reduction error). | Inform Service. |
| 17 | - | x | x | Excess current detection on wire feeder | Check wire feeding |
| 18 | - | x | x | No speedometer signal from second wire feeder (slave drive) | Check the connection and particularly the speedometer for the second wire feeder (slave drive). |
| 56 | - | - | x | Mains phase failure | Check mains voltages |
| 59 | - | - | x | Machine incompatible | Check machine used |
| 60 | - | - | x | Software update required | Inform Service. |

Legend for categories (reset error)

- a) The error message will disappear once the error has been rectified.
b) The error message can be reset by pressing a push-button:

| Welding machine control | Push-button |
|--|--|
| RC1 / RC2 |  |
| Expert |  |
| Expert 2.0 |  |
| CarExpert / Progress (M3.11) |  |
| alpha Q / Concept / Basic / Basic S / Synergic / Synergic S / Progress (M3.71) / Picomig 305 | not possible |

- c) The error message can only be reset by switching the machine off and on again.
The shielding gas error (Err 6) can be reset by pressing the "Welding parameters" key button.

7.3 Resetting JOBs (welding tasks) to the factory settings



All customised welding parameters that are stored will be replaced by the factory settings.

Instructions on how to reset welding tasks (JOBs) to the factory setting can be found in the JOB manager > see 5.6.2 chapter chapter.

8 Appendix A

8.1 Parameter overview – setting information

8.1.1 MIG/MAG welding

| Parameter GMAW | Setting range | | | | Display | Comment |
|-----------------------------------|---------------|--------|------|--------|---------|------------|
| | Standard | Unit | Min. | Max. | | |
| Gas pre-flow time | 0,1 | s | 0 | - 20 | | |
| Gas nominal value | | l/min. | | | | GFE option |
| Start program P _{START} | | | | | | |
| WF relative | 55 | % | 1 | - 200 | | |
| Duration | 0,1 | s | 0,00 | - 20,0 | | |
| U correction | 0 | V | -9,9 | - 9,9 | | |
| Slope time | 0,6 | s | 0,00 | 20,0 | | |
| Main program P _A | | | | | | |
| WF (/min.) | 0,01 | m/min | 0,00 | - 20,0 | | |
| U correction | 0 | V | -9,9 | - 9,9 | | |
| Duration | 0,15 | s | 0,00 | - 20,0 | | |
| Slope time | 0,10 | s | 0,00 | - 20,0 | | |
| Down-slope program P _B | | | | | | |
| WF relative | 60 | % | 0 | - 200 | | |
| Duration | 0,40 | s | 0,0 | - 20,0 | | |
| U correction | 0 | V | -9,9 | - 9,9 | | |
| Slope time | 0,05 | s | 0,00 | - 20,0 | | |
| Slope time | 0,00 | s | 0,00 | - 20,0 | | |
| End program P _{END} | | | | | | |
| WF relative | 100 | % | 0 | - 200 | | |
| Duration | 0,00 | s | 0,0 | - 20,0 | | |
| U correction | 0 | V | -9,9 | - 9,9 | | |
| Wire burn-back | 15 | | 0 | 499 | | |
| Gas post-flow time | 0,5 | s | 0,0 | 20,0 | | |

8.1.2 TIG welding

| Parameter TIG/plasma | Display | Setting range | | | Comment |
|-------------------------|---------|---------------|------|--------|--|
| | Unit | Standard | Min. | Max. | |
| Gas pre-flow time | s | 0,1 | 0 | - 20 | |
| Ignition current AMP% | % | 50 | 0 | - 200 | % of main current AMP |
| Start time | s | 0,5 | 0,00 | - 20,0 | |
| Up-slope time | s | 0,5 | 0,0 | - 20,0 | |
| Pulse current | % | 140 | 1 | 200 | |
| Pulse time | s | 0,2 | 0,01 | - 20,0 | |
| Slope time | s | 0,1 | 0,00 | - 20,0 | Time from main current AMP to secondary current AMP% |
| Secondary current AMP% | % | 50 | 1 | 200 | % of main current AMP |
| Pulse pause time | s | 0,2 | 0,01 | - 20,0 | |
| Slope time | s | 0,1 | 0,00 | - 20,0 | Time from main current AMP to secondary current AMP% |
| Down-slope time | s | 0,5 | 0,0 | - 20,0 | |
| End current AMP% | % | 30 | 0 | - 200 | % of main current AMP |
| End current time | s | 0,5 | 0,00 | - 20,0 | |
| Gas post-flow time | s | 5 | 0,0 | - 20,0 | |

8.1.3 MMA welding

Parameter MMA

| | Display | | Setting range | | | Comment |
|-------------------|---------|------|---------------|------|--------|---------|
| | | Unit | Standard | Min. | Max. | |
| Hot start current | | % | 120 | 1 | - 200 | |
| Hot start time | | s | 0.5 | 0.0 | - 10.0 | |
| Arcforce | | | 0 | -40 | - 40 | |

9 Appendix B

9.1 JOB-List

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|----------------------|---------------------------|-------------------------|---------------|
| 1 | Standard GMAW/pulse | G3Si1/G4Si1 | 100% CO2 | 0,8 |
| 2 | Standard GMAW/puls | G3Si1/G4Si1 | 100% CO2 | 0,9 |
| 3 | Standard GMAW/puls | G3Si1/G4Si1 | 100% CO2 | 1,0 |
| 4 | Standard GMAW/puls | G3Si1/G4Si1 | 100% CO2 | 1,2 |
| 5 | Standard GMAW/puls | G3Si1/G4Si1 | 100% CO2 | 1,6 |
| 6 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 7 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,9 |
| 8 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 9 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 10 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 11 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 0,8 |
| 12 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 0,9 |
| 13 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,0 |
| 14 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,2 |
| 15 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,6 |
| 26 | Standard GMAW/puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 27 | Standard GMAW/puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 28 | Standard GMAW/puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 29 | Standard GMAW/puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 30 | Standard GMAW/puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 31 | Standard GMAW/puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 32 | Standard GMAW/puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 33 | Standard GMAW/puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 34 | Standard GMAW/puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 35 | Standard GMAW/puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 36 | Standard GMAW/puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 37 | Standard GMAW/puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 38 | Standard GMAW/puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 39 | Standard GMAW/puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 40 | Standard GMAW/puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 41 | Standard GMAW/puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 42 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 43 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 44 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 45 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 46 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-78/H3-20/CO2-2 (M12) | 0,8 |
| 47 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-78/H3-20/CO2-2 (M12) | 1,0 |
| 48 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-78/H3-20/CO2-2 (M12) | 1,2 |
| 49 | Standard GMAW/puls | CrNi 22 9 3a/1.4462 | Ar-78/H3-20/CO2-2 (M12) | 1,6 |
| 50* | coldArc/coldArc puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 51* | coldArc/coldArc puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 52* | coldArc/coldArc puls | CrNi 19 9/1.4316 | Ar-97,5/CO2-2,5 (M12) | 1,2 |

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|----------------------|----------|-----------------------|---------------|
| 55* | coldArc/coldArc puls | AlMg | Ar-100 (I1) | 1,0 |
| 56* | coldArc/coldArc puls | AlMg | Ar-100 (I1) | 1,2 |
| 59* | coldArc/coldArc puls | AlSi | Ar-100 (I1) | 1,0 |
| 60* | coldArc/coldArc puls | AlSi | Ar-100 (I1) | 1,2 |
| 63* | coldArc/coldArc puls | Al99 | Ar-100 (I1) | 1,0 |
| 64* | coldArc/coldArc puls | Al99 | Ar-100 (I1) | 1,2 |
| 66* | coldArc brazing | CuSi | Ar-100 (I1) | 0,8 |
| 67* | coldArc brazing | CuSi | Ar-100 (I1) | 1,0 |
| 68* | coldArc brazing | CuSi | Ar-100 (I1) | 1,2 |
| 70* | coldArc brazing | CuAl | Ar-100 (I1) | 0,8 |
| 71* | coldArc brazing | CuAl | Ar-100 (I1) | 1,0 |
| 72* | coldArc brazing | CuAl | Ar-100 (I1) | 1,2 |
| 74 | Standard GMAW/puls | AlMg | Ar-100 (I1) | 0,8 |
| 75 | Standard GMAW/puls | AlMg | Ar-100 (I1) | 1,0 |
| 76 | Standard GMAW/puls | AlMg | Ar-100 (I1) | 1,2 |
| 77 | Standard GMAW/puls | AlMg | Ar-100 (I1) | 1,6 |
| 78 | Standard GMAW/puls | AlMg | Ar-70/He-30 (I3) | 0,8 |
| 79 | Standard GMAW/puls | AlMg | Ar-70/He-30 (I3) | 1,0 |
| 80 | Standard GMAW/puls | AlMg | Ar-70/He-30 (I3) | 1,2 |
| 81 | Standard GMAW/puls | AlMg | Ar-70/He-30 (I3) | 1,6 |
| 82 | Standard GMAW/puls | AlSi | Ar-100 (I1) | 0,8 |
| 83 | Standard GMAW/puls | AlSi | Ar-100 (I1) | 1,0 |
| 84 | Standard GMAW/puls | AlSi | Ar-100 (I1) | 1,2 |
| 85 | Standard GMAW/puls | AlSi | Ar-100 (I1) | 1,6 |
| 86 | Standard GMAW/puls | AlSi | Ar-70/He-30 (I3) | 0,8 |
| 87 | Standard GMAW/puls | AlSi | Ar-70/He-30 (I3) | 1,0 |
| 88 | Standard GMAW/puls | AlSi | Ar-70/He-30 (I3) | 1,2 |
| 89 | Standard GMAW/puls | AlSi | Ar-70/He-30 (I3) | 1,6 |
| 90 | Standard GMAW/puls | Al99 | Ar-100 (I1) | 0,8 |
| 91 | Standard GMAW/puls | Al99 | Ar-100 (I1) | 1,0 |
| 92 | Standard GMAW/puls | Al99 | Ar-100 (I1) | 1,2 |
| 93 | Standard GMAW/puls | Al99 | Ar-100 (I1) | 1,6 |
| 94 | Standard GMAW/puls | Al99 | Ar-70/He-30 (I3) | 0,8 |
| 95 | Standard GMAW/puls | Al99 | Ar-70/He-30 (I3) | 1,0 |
| 96 | Standard GMAW/puls | Al99 | Ar-70/He-30 (I3) | 1,2 |
| 97 | Standard GMAW/puls | Al99 | Ar-70/He-30 (I3) | 1,6 |
| 98 | Standard GMAW/puls | CuSi | Ar-100 (I1) | 0,8 |
| 99 | Standard GMAW/puls | CuSi | Ar-100 (I1) | 1,0 |
| 100 | Standard GMAW/puls | CuSi | Ar-100 (I1) | 1,2 |
| 101 | Standard GMAW/puls | CuSi | Ar-100 (I1) | 1,6 |
| 106 | Standard GMAW/puls | CuAl | Ar-100 (I1) | 0,8 |
| 107 | Standard GMAW/puls | CuAl | Ar-100 (I1) | 1,0 |
| 108 | Standard GMAW/puls | CuAl | Ar-100 (I1) | 1,2 |
| 109 | Standard GMAW/puls | CuAl | Ar-100 (I1) | 1,6 |
| 110 | Brazing | CuSi | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 111 | Brazing | CuSi | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 112 | Brazing | CuSi | Ar-97,5/CO2-2,5 (M12) | 1,2 |

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|---------------|----------------|-----------------------|---------------|
| 113 | Brazing | CuSi | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 114 | Brazing | CuSi | Ar-100 (I1) | 0,8 |
| 115 | Brazing | CuSi | Ar-100 (I1) | 1,0 |
| 116 | Brazing | CuSi | Ar-100 (I1) | 1,2 |
| 117 | Brazing | CuSi | Ar-100 (I1) | 1,6 |
| 118 | Brazing | CuAl | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 119 | Brazing | CuAl | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 120 | Brazing | CuAl | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 121 | Brazing | CuAl | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 122 | Brazing | CuAl | Ar-100 (I1) | 0,8 |
| 123 | Brazing | CuAl | Ar-100 (I1) | 1,0 |
| 124 | Brazing | CuAl | Ar-100 (I1) | 1,2 |
| 125 | Brazing | CuAl | Ar-100 (I1) | 1,6 |
| 126 | Gouging | | | |
| 127 | TIG Liftarc | | | |
| 128 | MMA | | | |
| 129 | Special JOB 1 | Free JOB | | |
| 130 | Special JOB 2 | Free JOB | | |
| 131 | Special JOB 3 | Free JOB | | |
| 132 | | Free JOB | | |
| 133 | | Free JOB | | |
| 134 | | Free JOB | | |
| 135 | | Free JOB | | |
| 136 | | Free JOB | | |
| 137 | | Free JOB | | |
| 138 | | Free JOB | | |
| 139 | | Free JOB | | |
| 140 | | Block 1/ JOB1 | | |
| 141 | | Block 1/ JOB2 | | |
| 142 | | Block 1/ JOB3 | | |
| 143 | | Block 1/ JOB4 | | |
| 144 | | Block 1/ JOB5 | | |
| 145 | | Block 1/ JOB6 | | |
| 146 | | Block 1/ JOB7 | | |
| 147 | | Block 1/ JOB8 | | |
| 148 | | Block 1/ JOB9 | | |
| 149 | | Block 1/ JOB10 | | |
| 150 | | Block 2/ JOB1 | | |
| 151 | | Block 2/ JOB2 | | |
| 152 | | Block 2/ JOB3 | | |
| 153 | | Block 2/ JOB4 | | |
| 154 | | Block 2/ JOB5 | | |
| 155 | | Block 2/ JOB6 | | |
| 156 | | Block 2/ JOB7 | | |
| 157 | | Block 2/ JOB8 | | |
| 158 | | Block 2/ JOB9 | | |
| 159 | | Block 2/ JOB10 | | |

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|------------------------------|----------------|--------------------|---------------|
| 160 | | Block 3/ JOB1 | | |
| 161 | | Block 3/ JOB2 | | |
| 162 | | Block 3/ JOB3 | | |
| 163 | | Block 3/ JOB4 | | |
| 164 | | Block 3/ JOB5 | | |
| 165 | | Block 3/ JOB6 | | |
| 166 | | Block 3/ JOB7 | | |
| 167 | | Block 3/ JOB8 | | |
| 168 | | Block 3/ JOB9 | | |
| 169 | | Block 3/ JOB10 | | |
| 171* | pipeSolution | G3Si1/G4Si1 | CO2-100 (C1) | 1,0 |
| 172* | pipeSolution | G3Si1/G4Si1 | CO2-100 (C1) | 1,2 |
| 173* | pipeSolution | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 174* | pipeSolution | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 177 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,0 |
| 178 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,2 |
| 179 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 180 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 181 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 182* | coldArc/coldArc puls | G3Si1/G4Si1 | CO2-100 (C1) | 0,8 |
| 184* | coldArc/coldArc puls | G3Si1/G4Si1 | CO2-100 (C1) | 1,0 |
| 185* | coldArc/coldArc puls | G3Si1/G4Si1 | CO2-100 (C1) | 1,2 |
| 187 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | |
| 188 | Standard GMAW/puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | |
| 189 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 190 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 191* | coldArc/coldArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 193* | coldArc/coldArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 194* | coldArc/coldArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 195* | coldArc/coldArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 197* | coldArc brazing | AlSi | Ar-100 (I1) | 1,0 |
| 198* | coldArc brazing | AlSi | Ar-100 (I1) | 1,2 |
| 201* | coldArc brazing | ZnAl | Ar-100 (I1) | 1,0 |
| 202* | coldArc brazing | ZnAl | Ar-100 (I1) | 1,2 |
| 204 | rootArc/rootArc puls | G3Si1/G4Si1 | CO2-100 (C1) | 1,0 |
| 205 | rootArc/rootArc puls | G3Si1/G4Si1 | CO2-100 (C1) | 1,2 |
| 206 | rootArc/rootArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 207 | rootArc/rootArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 208* | coldArc - Mg/Mg | Mg | Ar-70/H3-30 (I3) | 1,2 |
| 209* | coldArc - Mg/Mg | Mg | Ar-70/H3-30 (I3) | 1,6 |
| 210 | Rutile/basic flux cored wire | CrNi | CO2-100 (C1) | 0,9 |
| 211 | Rutile/basic flux cored wire | CrNi | CO2-100 (C1) | 1,0 |
| 212 | Rutile/basic flux cored wire | CrNi | CO2-100 (C1) | 1,2 |
| 213 | Rutile/basic flux cored wire | CrNi | CO2-100 (C1) | 1,6 |

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|------------------------------|---------------------|-----------------------|---------------|
| 214 | Surfacing | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 215 | Surfacing | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,9 |
| 216 | Surfacing | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 217 | Surfacing | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 218 | Surfacing | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 220* | coldArc - St/Al | ZnAl | Ar-100 (I1) | 1,0 |
| 221* | coldArc - St/Al | ZnAl | Ar-100 (I1) | 1,2 |
| 224* | coldArc - St/Al | AlSi | Ar-100 (I1) | 1,0 |
| 225* | coldArc - St/Al | AlSi | Ar-100 (I1) | 1,2 |
| 227 | Metal flux-cored wire | CrNi | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 228 | Metal flux-cored wire | CrNi | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 229 | Metal flux-cored wire | CrNi | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 230 | Metal flux-cored wire | CrNi | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 231 | Rutile/basic flux cored wire | CrNi | Ar-82/CO2-18 (M21) | 0,9 |
| 232 | Rutile/basic flux cored wire | CrNi | Ar-82/CO2-18 (M21) | 1,0 |
| 233 | Rutile/basic flux cored wire | CrNi | Ar-82/CO2-18 (M21) | 1,2 |
| 234 | Rutile/basic flux cored wire | CrNi | Ar-82/CO2-18 (M21) | 1,6 |
| 235 | Metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 237 | Metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 238 | Metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 239 | Metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 240 | Rutile/basic flux cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 242 | Rutile/basic flux cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 243 | Rutile/basic flux cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 244 | Rutile/basic flux cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 245 | forceArc/forceArc puls | Al99 | Ar-100 (I1) | 1,2 |
| 246 | forceArc/forceArc puls | Al99 | Ar-100 (I1) | 1,6 |
| 247 | forceArc/forceArc puls | AlMg | Ar-100 (I1) | 1,2 |
| 248 | forceArc/forceArc puls | AlMg | Ar-100 (I1) | 1,6 |
| 249 | forceArc/forceArc puls | AlSi | Ar-100 (I1) | 1,2 |
| 250 | forceArc/forceArc puls | AlSi | Ar-100 (I1) | 1,6 |
| 251 | forceArc/forceArc puls | CrNi | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 252 | forceArc/forceArc puls | CrNi | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 253 | forceArc/forceArc puls | CrNi | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 254 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,0 |
| 255 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,2 |
| 256 | forceArc/forceArc puls | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,6 |
| 260 | Rutile/basic flux cored wire | G3Si1/G4Si1 | CO2-100 (C1) | 1,2 |
| 261 | Rutile/basic flux cored wire | G3Si1/G4Si1 | CO2-100 (C1) | 1,6 |
| 263 | Metal flux-cored wire | High tensile steels | Ar-82/CO2-18 (M21) | 1,2 |

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|--|------------------------|--------------------------------|---------------|
| 264 | Basic flux-cored | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 268 | Standard GMAW/puls | NiCr 617 | Ar-70/He-30 (I3) | 1,2 |
| 269 | Standard GMAW/puls | NiCr 617 | Ar-70/He-30 (I3) | 1,6 |
| 271 | Standard GMAW/puls | NiCr 625 | Ar-70/He-30 (I3) | 1,0 |
| 272 | Standard GMAW/puls | NiCr 625 | Ar-70/He-30 (I3) | 1,2 |
| 273 | Standard GMAW/puls | NiCr 625 | Ar-70/He-30 (I3) | 1,6 |
| 275 | Standard GMAW/puls | NiCr 625 | Ar-67,95/He-30/H2-2 / CO2-0,05 | 1,0 |
| 276 | Standard GMAW/puls | NiCr 625 | Ar-67,95/He-30/H2-2 / CO2-0,05 | 1,2 |
| 277 | Standard GMAW/puls | NiCr 625 | Ar-78/H3-20/CO2-2 (M12) | 1,6 |
| 279 | Standard GMAW/puls | CrNi 25 20/1.4842 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 280 | Standard GMAW/puls | CrNi 25 20/1.4842 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 282 | Standard GMAW/puls | CrNi 22 12/1.4829 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 283 | Standard GMAW/puls | CrNi 22 12/1.4829 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 284 | Standard GMAW/puls | CrNi 22 12/1.4829 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 285 | Standard GMAW/puls | CrNi 22 12/1.4829 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 290 | forceArc / forceArc puls metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 291 | forceArc / forceArc puls metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 292 | forceArc / forceArc puls metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 293 | forceArc / forceArc puls metal flux-cored wire | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 294 | forceArc/pulsea | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 0,8 |
| 295 | forceArc/pulse | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 296 | forceArc/pulse | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |
| 297 | forceArc/pulse | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,6 |
| 298 | forceArc/pulse | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 0,8 |
| 299 | forceArc/pulse | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,0 |
| 300 | forceArc/pulse | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,2 |
| 301 | forceArc/pulse | G3Si1/G4Si1 | Ar-90/CO2-10 (M20) | 1,6 |
| 302 | forceArc/forceArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 303 | forceArc/forceArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 304 | forceArc/forceArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 305 | forceArc/forceArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 306 | forceArc/forceArc puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 307 | forceArc/forceArc puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 308 | forceArc/forceArc puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 309 | forceArc/forceArc puls | CrNi 18 8/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 310 | forceArc/forceArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 311 | forceArc/forceArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 312 | forceArc/forceArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 313 | forceArc/forceArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 314 | forceArc/forceArc puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 0,8 |

| JOB no. | Processes | Material | Gas | Diameter [mm] |
|---------|------------------------|------------------------------|-----------------------|---------------|
| 315 | forceArc/forceArc puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 316 | forceArc/forceArc puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 317 | forceArc/forceArc puls | CrNi 22 9 3a/1.4462 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 319 | forceArc/forceArc puls | CrNi 25 20/1.4842 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 320 | forceArc/forceArc puls | CrNi 25 20/1.4842 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 323 | forceArc/forceArc puls | CrNi 22 12/1.4829 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 324 | forceArc/forceArc puls | CrNi 22 12/1.4829 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 326* | coldArc/coldArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 327* | coldArc/coldArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 328* | coldArc/coldArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 329* | coldArc/coldArc puls | CrNi 19 12 3 Nb/1.4576 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 330* | coldArc/coldArc puls | CrNi 18 8 Mn/1.4370 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 331* | coldArc/coldArc puls | CrNi 18 8 Mn/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 332* | coldArc/coldArc puls | CrNi 18 8 Mn/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 333* | coldArc/coldArc puls | CrNi 18 8 Mn/1.4370 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 334* | coldArc/coldArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 335* | coldArc/coldArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 336* | coldArc/coldArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 337* | coldArc/coldArc puls | CrNi 19 12 3/1.4430 | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 338* | coldArc/coldArc puls | CrNi 22 9 3/1.4462/Duplex | Ar-97,5/CO2-2,5 (M12) | 0,8 |
| 339* | coldArc/coldArc puls | CrNi 22 9 3/1.4462/Duplex | Ar-97,5/CO2-2,5 (M12) | 1,0 |
| 340* | coldArc/coldArc puls | CrNi 22 9 3/1.4462/Duplex | Ar-97,5/CO2-2,5 (M12) | 1,2 |
| 341* | coldArc/coldArc puls | CrNi 22 9 3/1.4462/Duplex | Ar-97,5/CO2-2,5 (M12) | 1,6 |
| 359 | wiredArc/wiredArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,0 |
| 360 | wiredArc/wiredArc puls | G3Si1/G4Si1 | Ar-82/CO2-18 (M21) | 1,2 |

* Active for the alpha Q machine series only.

10 Appendix C

10.1 Overview of EWM branches

Headquarters

EWM AG
Dr. Günter-Henle-Straße 8
56271 Mündersbach · Germany
Tel: +49 2680 181-0 · Fax: -244
www.ewm-group.com · info@ewm-group.com

Technology centre

EWM AG
Forststraße 7-13
56271 Mündersbach · Germany
Tel: +49 2680 181-0 · Fax: -144
www.ewm-group.com · info@ewm-group.com

Production, Sales and Service

EWM AG
Dr. Günter-Henle-Straße 8
56271 Mündersbach · Germany
Tel: +49 2680 181-0 · Fax: -244
www.ewm-group.com · info@ewm-group.com

EWM HIGH TECHNOLOGY (Kunshan) Ltd.
10 Yuanshan Road, Kunshan · New & Hi-tech Industry Development Zone
Kunshan City · Jiangsu · Post code 215300 · People's Republic of China
Tel: +86 512 57867-188 · Fax: -182
www.ewm.cn · info@ewm.cn · info@ewm-group.cn

EWM HIGHTEC WELDING s.r.o.
9. května 718 / 31
407 53 Jiríkov · Czech Republic
Tel.: +420 412 358-551 · Fax: -504
www.ewm-jiríkov.cz · info@ewm-jiríkov.cz

Sales and Service Germany

EWM AG
Sales and Technology Centre
Grünauer Fenn 4
14712 Rathenow · Tel: +49 3385 49402-0 · Fax: -20
www.ewm-rathenow.de · info@ewm-rathenow.de

EWM AG
Rudolf-Winkel-Straße 7-9
37079 Göttingen · Tel: +49 551-3070713-0 · Fax: -20
www.ewm-goettingen.de · info@ewm-goettingen.de

EWM AG
Dieselstraße 9b
50259 Pulheim · Tel: +49 2238-46466-0 · Fax: -14
www.ewm-pulheim.de · info@ewm-pulheim.de

EWM AG
August-Horch-Straße 13a
56070 Koblenz · Tel: +49 261 963754-0 · Fax: -10
www.ewm-koblenz.de · info@ewm-koblenz.de

EWM AG
Eiserfelder Straße 300
57080 Siegen · Tel: +49 271 3878103-0 · Fax: -9
www.ewm-siegen.de · info@ewm-siegen.de

EWM HIGHTEC WELDING GmbH
Centre Technology and mechanisation
Daimlerstr. 4-6
69469 Weinheim · Tel: +49 6201 84557-0 · Fax: -20
www.ewm-weinheim.de · info@ewm-weinheim.de

EWM Schweißtechnik Handels GmbH
Karlsdorfer Straße 43
88069 Tett nang · Tel: +49 7542 97998-0 · Fax: -29
www.ewm-tett nang.de · info@ewm-tett nang.de

EWM Schweißtechnik Handels GmbH
Heinkelstraße 8
89231 Neu-Ulm · Tel: +49 731 7047939-0 · Fax: -15
www.ewm-neu-ulm.de · info@ewm-neu-ulm.de

Sales and Service International

EWM HIGH TECHNOLOGY (Kunshan) Ltd.
10 Yuanshan Road, Kunshan · New & Hi-tech Industry Development Zone
Kunshan City · Jiangsu · Post code 215300 · People's Republic of China
Tel: +86 512 57867-188 · Fax: -182
www.ewm.cn · info@ewm.cn · info@ewm-group.cn

EWM HIGHTEC WELDING GmbH
Wiesenstraße 27b
4812 Pinsdorf · Austria · Tel: +43 7612 778 02-0 · Fax: -20
www.ewm-austria.at · info@ewm-austria.at

EWM HIGHTEC WELDING UK Ltd.
Unit 2B Coopies Way · Coopies Lane Industrial Estate
Morpeth · Northumberland · NE61 6JN · Great Britain
Tel: +44 1670 505875 · Fax: -514305
www.ewm-morpeth.co.uk · info@ewm-morpeth.co.uk

EWM HIGHTEC WELDING Sales s.r.o. / Prodejní a poradenské centrum
Tyršova 2106
256 01 Benešov u Prahy · Czech Republic
Tel: +420 317 729-517 · Fax: -712
www.ewm-benesov.cz · info@ewm-benesov.cz

Liaison office Turkey

EWM AG Türkiye İrtibat Bürosu
İkitelli OSB Mah. · Marmara Sanayi Sitesi P Blok Apt. No: 44
Küçükçekmece / İstanbul Türkiye
Tel.: +90 212 494 32 19
www.ewm-istanbul.com.tr · info@ewm-istanbul.com.tr

 Plants

 Branches

 Liaison office

● More than 400 EWM sales partners worldwide