



**EN**

## Welding machine

**Taurus XQ 355 Synergic**  
**Taurus XQ 405 Synergic**  
**Taurus XQ 505 Synergic**

099-005664-EW501

Observe additional system documents!

22.09.2021

**Register now  
and benefit!**  
**Jetzt Registrieren  
und Profitieren!**

[www.ewm-group.com](http://www.ewm-group.com)



# General instructions

## WARNING



### **Read the operating instructions!**

#### **The operating instructions provide an introduction to the safe use of the products.**

- Read and observe the operating instructions for all system components, especially the safety instructions and warning notices!
- Observe the accident prevention regulations and any regional regulations!
- The operating instructions must be kept at the location where the machine is operated.
- Safety and warning labels on the machine indicate any possible risks. Keep these labels clean and legible at all times.
- The machine has been constructed to state-of-the-art standards in line with any applicable regulations and industrial standards. Only trained personnel may operate, service and repair the machine.
- Technical changes due to further development in machine technology may lead to a differing welding behaviour.

**In the event of queries on installation, commissioning, operation or special conditions at the installation site, or on usage, please contact your sales partner or our customer service department on +49 2680 181-0.**

**A list of authorised sales partners can be found at [www.ewm-group.com/en/specialist-dealers](http://www.ewm-group.com/en/specialist-dealers).**

Liability relating to the operation of this equipment is restricted solely to the function of the equipment. No other form of liability, regardless of type, shall be accepted. This exclusion of liability shall be deemed accepted by the user on commissioning the equipment.

The manufacturer is unable to monitor whether or not these instructions or the conditions and methods are observed during installation, operation, usage and maintenance of the equipment.

An incorrectly performed installation can result in material damage and injure persons as a result. For this reason, we do not accept any responsibility or liability for losses, damages or costs arising from incorrect installation, improper operation or incorrect usage and maintenance or any actions connected to this in any way.

### **© EWM AG**

Dr. Günter-Henle-Strasse 8

56271 Mündersbach Germany

Tel.: +49 2680 181-0, Fax: -244

Email: [info@ewm-group.com](mailto:info@ewm-group.com)

**[www.ewm-group.com](http://www.ewm-group.com)**

The copyright to this document remains the property of the manufacturer.

Copying, including extracts, only permitted with written approval.

The content of this document has been prepared and reviewed with all reasonable care. The information provided is subject to change; errors excepted.

### **Data security**

The user is responsible for backing up data of all changes from the factory setting. The user is liable for erased personal settings. The manufacturer does not assume any liability for this.

# 1 Contents

<b>1</b>	<b>Contents</b> .....	<b>3</b>
<b>2</b>	<b>For your safety</b> .....	<b>6</b>
2.1	Notes on using these operating instructions .....	6
2.2	Explanation of icons .....	7
2.3	Safety instructions.....	8
2.4	Transport and installation .....	11
<b>3</b>	<b>Intended use</b> .....	<b>13</b>
3.1	Applications.....	13
3.2	Documents which also apply .....	13
3.2.1	Warranty .....	13
3.2.2	Declaration of Conformity .....	13
3.2.3	Welding in environments with increased electrical hazards .....	14
3.2.4	Service documents (spare parts and circuit diagrams) .....	14
3.2.5	Calibration/Validation.....	14
3.3	Use and operation solely with the following machines .....	14
3.3.1	Part of the complete documentation.....	15
<b>4</b>	<b>Machine description – quick overview</b> .....	<b>16</b>
4.1	Front view / rear view .....	16
4.1.1	Connection panel.....	18
<b>5</b>	<b>Design and function</b> .....	<b>19</b>
5.1	Transport and installation .....	19
5.1.1	Ambient conditions .....	19
5.1.2	Machine cooling.....	20
5.1.3	Workpiece lead, general.....	20
5.1.4	Welding torch cooling system.....	20
5.1.4.1	Cooling unit connection.....	20
5.1.5	Connecting the intermediate hose package to the power source .....	20
5.1.6	Mains connection.....	22
5.1.6.1	Visual inspection of the set mains voltage .....	22
5.1.6.2	Adjusting the power source to the mains voltage .....	23
5.1.6.3	Re-commissioning.....	23
5.1.6.4	Mains configuration .....	24
5.1.7	Switching on and system diagnosis .....	24
5.1.8	Notes on the installation of welding current leads .....	25
5.1.9	Stray welding currents .....	26
5.2	MIG/MAG welding.....	27
5.2.1	Connection for workpiece lead .....	27
5.2.2	Welding torch connection .....	27
5.2.3	Welding task selection.....	27
5.3	MMA welding or gouging .....	27
5.3.1	MMA welding .....	27
5.3.2	Air arc gouging .....	27
5.3.3	Connection of electrode holder or gouging torch .....	28
5.3.4	Connection of the electrode holder / gouging torch over the wire feeder .....	29
5.3.5	Welding task selection.....	29
5.4	TIG welding.....	30
5.4.1	Connection .....	30
5.4.2	Welding task selection.....	30
5.5	Remote control.....	30
5.6	Interfaces for automation .....	30
5.6.1	Automation interface.....	31
5.6.2	RINT X12 robot interface.....	31
5.6.3	BUSINT X11 industrial bus interface .....	31
5.7	Network connection .....	32
5.8	PC interface .....	32
5.8.1	Connection .....	32
5.9	Component identification .....	33

<b>6</b>	<b>Maintenance, care and disposal</b>	<b>34</b>
6.1	General	34
6.1.1	Cleaning	34
6.1.2	Dirt filter	34
6.2	Maintenance work, intervals	35
6.2.1	Daily maintenance tasks	35
6.2.2	Monthly maintenance tasks	35
6.2.3	Annual test (inspection and testing during operation)	35
6.3	Disposing of equipment	36
<b>7</b>	<b>Rectifying faults</b>	<b>37</b>
7.1	Error messages (power source)	37
7.2	Warnings	40
7.3	Checklist for rectifying faults	42
<b>8</b>	<b>Technical data</b>	<b>44</b>
8.1	Dimensions and weights	44
8.2	Taurus XQ 355 Synergic	45
8.3	Taurus XQ 405 Synergic	46
8.4	Taurus XQ 505 Synergic	47
<b>9</b>	<b>Accessories</b>	<b>48</b>
9.1	General accessories	48
9.2	7-pole remote control	48
9.3	Options	48
9.4	Transport system	48
9.5	Welding torch cooling system	48
9.5.1	Coolant - type blueCool	49
9.5.2	Coolant - type KF	49
9.6	Computer communication	49
9.7	Component identification	49
<b>10</b>	<b>Appendix</b>	<b>50</b>
10.1	Searching for a dealer	50



## 2 For your safety

### 2.1 Notes on using these operating instructions

#### **DANGER**

**Working or operating procedures which must be closely observed to prevent imminent serious and even fatal injuries.**

- Safety notes include the "DANGER" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol on the edge of the page.

#### **WARNING**

**Working or operating procedures which must be closely observed to prevent serious and even fatal injuries.**

- Safety notes include the "WARNING" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol in the page margin.

#### **CAUTION**

**Working or operating procedures which must be closely observed to prevent possible minor personal injury.**

- The safety information includes the "CAUTION" keyword in its heading with a general warning symbol.
- The risk is explained using a symbol on the edge of the page.



***Technical aspects which the user must observe to avoid material or equipment damage.***

Instructions and lists detailing step-by-step actions for given situations can be recognised via bullet points, e.g.:

- Insert the welding current lead socket into the relevant socket and lock.

## 2.2 Explanation of icons

Symbol	Description	Symbol	Description
	Indicates technical aspects which the user must observe.		Activate and release / Tap / Tip
	Switch off machine		Release
	Switch on machine		Press and hold
			Switch
	Incorrect / Invalid		Turn
	Correct / Valid		Numerical value – adjustable
	Input		Signal light lights up in green
	Navigation		Signal light flashes green
	Output		Signal light lights up in red
	Time representation (e.g.: wait 4 s / actuate)		Signal light flashes red
	Interruption in the menu display (other setting options possible)		
	Tool not required/do not use		
	Tool required/use		

## 2.3 Safety instructions

### **WARNING**



**Risk of accidents due to non-compliance with the safety instructions!**

**Non-compliance with the safety instructions can be fatal!**

- Carefully read the safety instructions in this manual!
- Observe the accident prevention regulations and any regional regulations!
- Inform persons in the working area that they must comply with the regulations!



**Risk of injury from electrical voltage!**

**Voltages can cause potentially fatal electric shocks and burns on contact. Even low voltages can cause a shock and lead to accidents.**

- Never touch live components such as welding current sockets or stick, tungsten or wire electrodes!
- Always place torches and electrode holders on an insulated surface!
- Wear the full personal protective equipment (depending on the application)!
- The machine may only be opened by qualified personnel!
- The device must not be used to defrost pipes!



**Hazard when interconnecting multiple power sources!**

**If a number of power sources are to be connected in parallel or in series, only a technical specialist may interconnect the sources as per standard IEC 60974-9:2010: Installation and use and German Accident Prevention Regulation BVG D1 (formerly VBG 15) or country-specific regulations.**

**Before commencing arc welding, a test must verify that the equipment cannot exceed the maximum permitted open circuit voltage.**

- Only qualified personnel may connect the machine.
- When taking individual power sources out of operation, all mains and welding current leads must be safely disconnected from the welding system as a whole. (Hazard due to reverse polarity voltage!)
- Do not interconnect welding machines with pole reversing switch (PWS series) or machines for AC welding since a minor error in operation can cause the welding voltages to be combined, which is not permitted.



**Risk of injury due to radiation or heat!**

**Arc radiation can lead to skin and eye injuries.**

**Contact with hot workpieces and sparks can lead to burns.**

- Use hand shield or welding helmet with the appropriate safety level (depends on the application).
- Wear dry protective clothing (e.g. hand shield, gloves, etc.) in accordance with the applicable regulations of your country.
- Persons who are not directly involved should be protected with a welding curtain or suitable safety screen against radiation and the risk of blinding!



 **WARNING****Risk of injury due to improper clothing!**

**During arc welding, radiation, heat and voltage are sources of risk that cannot be avoided. The user has to be equipped with the complete personal protective equipment at all times. The protective equipment has to include:**

- Respiratory protection against hazardous substances and mixtures (fumes and vapours); otherwise implement suitable measures such as extraction facilities.
- Welding helmet with proper protection against ionizing radiation (IR and UV radiation) and heat.
- Dry welding clothing (shoes, gloves and body protection) to protect against warm environments with conditions comparable to ambient temperatures of 100 °C or higher and arcing and work on live components.
- Hearing protection against harming noise.

**Explosion risk!**

**Apparently harmless substances in closed containers may generate excessive pressure when heated.**

- Move containers with inflammable or explosive liquids away from the working area!
- Never heat explosive liquids, dusts or gases by welding or cutting!

**Fire hazard!**

**Due to the high temperatures, sparks, glowing parts and hot slag that occur during welding, there is a risk of flames.**

- Be watchful of potential sources of fire in the working area!
- Do not carry any easily inflammable objects, e.g. matches or lighters.
- Ensure suitable fire extinguishers are available in the working area!
- Thoroughly remove any residue of flammable materials from the workpiece prior to starting to weld.
- Only further process workpieces after they have cooled down. Do not allow them to contact any flammable materials!

## ⚠ CAUTION



### Smoke and gases!

**Smoke and gases can lead to breathing difficulties and poisoning. In addition, solvent vapour (chlorinated hydrocarbon) may be converted into poisonous phosgene due to the ultraviolet radiation of the arc!**

- Ensure that there is sufficient fresh air!
- Keep solvent vapour away from the arc beam field!
- Wear suitable breathing apparatus if appropriate!



### Noise exposure!

**Noise exceeding 70 dBA can cause permanent hearing damage!**

- Wear suitable ear protection!
- Persons located within the working area must wear suitable ear protection!



**According to IEC 60974-10, welding machines are divided into two classes of electromagnetic compatibility (the EMC class can be found in the Technical data):**

**Class A** machines are not intended for use in residential areas where the power supply comes from the low-voltage public mains network. When ensuring the electromagnetic compatibility of class A machines, difficulties can arise in these areas due to interference not only in the supply lines but also in the form of radiated interference.



**Class B** machines fulfil the EMC requirements in industrial as well as residential areas, including residential areas connected to the low-voltage public mains network.



### Setting up and operating

When operating arc welding systems, in some cases, electro-magnetic interference can occur although all of the welding machines comply with the emission limits specified in the standard. The user is responsible for any interference caused by welding.

In order to **evaluate** any possible problems with electromagnetic compatibility in the surrounding area, the user must consider the following: (see also EN 60974-10 Appendix A)

- Mains, control, signal and telecommunication lines
- Radios and televisions
- Computers and other control systems
- Safety equipment
- The health of neighbouring persons, especially if they have a pacemaker or wear a hearing aid
- Calibration and measuring equipment
- The immunity to interference of other equipment in the surrounding area
- The time of day at which the welding work must be carried out

### Recommendations for **reducing interference emission**

- Mains connection, e.g. additional mains filter or shielding with a metal tube
- Maintenance of the arc welding system
- Welding leads should be as short as possible and run closely together along the ground
- Potential equalization
- Earthing of the workpiece. In cases where it is not possible to earth the workpiece directly, it should be connected by means of suitable capacitors.
- Shielding from other equipment in the surrounding area or the entire welding system



### Electromagnetic fields!

**The power source may cause electrical or electromagnetic fields to be produced which could affect the correct functioning of electronic equipment such as IT or CNC devices, telecommunication lines, power cables, signal lines and pacemakers.**



- Observe the maintenance instructions > see 6.2 chapter!
- Unwind welding leads completely!
- Shield devices or equipment sensitive to radiation accordingly!
- The correct functioning of pacemakers may be affected (obtain advice from a doctor if necessary).

**⚠ CAUTION****Obligations of the operator!**

**The respective national directives and laws must be complied with when operating the machine!**

- Implementation of national legislation relating to framework directive 89/391/EEC on the introduction of measures to encourage improvements in the safety and health of workers at work and associated individual guidelines.
- In particular, directive 89/655/EEC concerning the minimum safety and health requirements for the use of work equipment by workers at work.
- The regulations applicable to occupational safety and accident prevention in the country concerned.
- Setting up and operating the machine as per IEC 60974.-9.
- Brief the user on safety-conscious work practices on a regular basis.
- Regularly inspect the machine as per IEC 60974.-4.



***The manufacturer's warranty becomes void if non-genuine parts are used!***

- ***Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!***
- ***Only insert and lock accessory components into the relevant connection socket when the machine is switched off.***

**Requirements for connection to the public mains network**

High-performance machines can influence the mains quality by taking current from the mains network. For some types of machines, connection restrictions or requirements relating to the maximum possible line impedance or the necessary minimum supply capacity at the interface with the public network (Point of Common Coupling, PCC) can therefore apply. In this respect, attention is also drawn to the machines' technical data. In this case, it is the responsibility of the operator, where necessary in consultation with the mains network operator, to ensure that the machine can be connected.

## 2.4 Transport and installation

**⚠ WARNING****Risk of injury due to improper handling of shielding gas cylinders!**

**Improper handling and insufficient securing of shielding gas cylinders can cause serious injuries!**

- Observe the instructions from the gas manufacturer and any relevant regulations concerning the use of compressed air!
- Do not attach any element to the shielding gas cylinder valve!
- Prevent the shielding gas cylinder from heating up.

## CAUTION



### **Risk of accidents due to supply lines!**

During transport, attached supply lines (mains leads, control cables, etc.) can cause risks, e.g. by causing connected machines to tip over and injure persons!

- Disconnect all supply lines before transport!



### **Risk of tipping!**

There is a risk of the machine tipping over and injuring persons or being damaged itself during movement and set up. Tilt resistance is guaranteed up to an angle of 10° (according to IEC 60974-1).

- Set up and transport the machine on level, solid ground.
- Secure add-on parts using suitable equipment.



### **Risk of accidents due to incorrectly installed leads!**

Incorrectly installed leads (mains, control and welding leads or intermediate hose packages ) can present a tripping hazard.

- Lay the supply lines flat on the floor (avoid loops).
- Avoid laying the leads on passage ways.



### **Risk of injury from heated coolant and its connections!**

The coolant used and its connection or connection points can heat up significantly during operation (water-cooled version). When opening the coolant circuit, escaping coolant may cause scalding.

- Open the coolant circuit only when the power source or cooling unit is switched off!
- Wear proper protective equipment (protective gloves)!
- Seal open connections of the hose leads with suitable plugs.



***The units are designed for operation in an upright position!***

***Operation in non-permissible positions can cause equipment damage.***

- ***Only transport and operate in an upright position!***



***Accessory components and the power source itself can be damaged by incorrect connection!***

- ***Only insert and lock accessory components into the relevant connection socket when the machine is switched off.***
- ***Comprehensive descriptions can be found in the operating instructions for the relevant accessory components.***
- ***Accessory components are detected automatically after the power source is switched on.***



***Protective dust caps protect the connection sockets and therefore the machine against dirt and damage.***

- ***The protective dust cap must be fitted if there is no accessory component being operated on that connection.***
- ***The cap must be replaced if faulty or if lost!***

### 3 Intended use

**⚠ WARNING**

**§ Hazards due to improper usage!**  
The machine has been constructed to the state of the art and any regulations and standards applicable for use in industry and trade. It may only be used for the welding procedures indicated at the rating plate. Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!

- The equipment must only be used in line with its designated purpose and by trained or expert personnel!
- Do not improperly modify or convert the equipment!

### 3.1 Applications

Multi-process welding machine for arc welding covering the following welding procedures:

Machine series	Main procedure for MIG/MAG welding											Secondary procedure			
	Standard arc					Pulsed arc						TIG welding (Liftarc)	MMA welding	Gouging	Positionweld
	MIG/MAG XQ	forceArc XQ	rootArc XQ	coldArc XQ	wiredArc XQ	MIG/MAG pulse XQ	forceArc puls XQ	rootArc puls XQ	coldArc puls XQ	acArc puls XQ	wiredArc puls XQ				
Titan XQ AC	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Titan XQ / XQ C	✓	✓	✓	✓	✓	✓	✓	✓	✓	✗	✓	✓	✓	✓	✓
Phoenix XQ / XQ C	✓	✓	✓	✗	✗	✓	✓	✓	✗	✗	✗	✓	✓	✓	☐ <sup>[1]</sup>
Taurus XQ / XQ C	✓	✓	✓	✗	✗	✗	✗	✗	✗	✗	✗	✓	✓	✓	✗
Taurus XQ Basic	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✓	✓	✗

[1] Aluminium-welding tasks

### 3.2 Documents which also apply

#### 3.2.1 Warranty

For more information refer to the "Warranty registration" brochure supplied and our information regarding warranty, maintenance and testing at [www.ewm-group.com](http://www.ewm-group.com)!

#### 3.2.2 Declaration of Conformity

**CE** This product corresponds in its design and construction to the EU directives listed in the declaration. The product comes with a relevant declaration of conformity in the original.  
The manufacturer recommends carrying out the safety inspection according to national and international standards and guidelines every 12 months.

## 3.2.3 Welding in environments with increased electrical hazards



Power sources with this marking can be used for welding in an environment with increased electrical hazard (e.g. boilers). For this purpose, appropriate national or international regulations must be followed. The power source must not be placed in the danger zone!

## 3.2.4 Service documents (spare parts and circuit diagrams)



### **WARNING**

**Do not carry out any unauthorised repairs or modifications!**  
**To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!**  
**The warranty becomes null and void in the event of unauthorised interference.**

- Appoint only skilled persons for repair work (trained service personnel)!

Original copies of the circuit diagrams are enclosed with the unit.

Spare parts can be obtained from the relevant authorised dealer.

## 3.2.5 Calibration/Validation

An original certificate is enclosed with the product. The manufacturer recommends calibration / validation at intervals of 12 months.

## 3.3 Use and operation solely with the following machines

**A suitable wire feed unit (system component) is required in order to operate the welding machine!**

The following system components can be combined:

<b>Power source</b>	Taurus XQ 355 Synergic Taurus XQ 405 Synergic Taurus XQ 505 Synergic
<b>Wire feed unit</b>	Drive XQ HP Drive XQ LP Drive XQ EX Drive XQ DV200
<b>Welding torch cooling unit</b>	Cool 50-2 U40 Cool 50-2 U42
<b>Transport vehicle</b>	Trolly 35-6 Trolly XQ 55.5 Trolly 55.6 Trolly 55.6 DF

### 3.3.1 Part of the complete documentation

This document is part of the complete documentation and valid only in combination with all other parts of these instructions! Read and observe the operating instructions for all system components, especially the safety instructions!

The illustration shows a general example of a welding system.




Figure 3-1

Item	Documentation
A.1	Wire feeder
A.2	Conversion instructions
A.3	Power source
A.4	Cooling unit, voltage converter, tool box etc.
A.5	Trolley
A.6	Welding torch
A.7	Remote control
A.8	Control
A	Complete documentation

## 4 Machine description – quick overview

### 4.1 Front view / rear view








Figure 4-1



Item	Symbol	Description
1		<b>Carrying handle</b>
2		<b>Ready for operation signal light</b> Signal light on when the machine is switched on and ready for operation
3		<b>Main Switch</b> Switching the machine on or off.
4		<b>Cooling air inlet</b> Dirt filter optional > see 6.1.2 chapter
5		<b>Machine feet</b>
6		<b>Connection panel &gt; see 4.1.1 chapter</b>
7		<b>Cooling air outlet</b>
8		<b>Connection socket, “+” welding current</b> How to connect the accessories depends on the welding procedure. Please observe the connection description for the corresponding welding procedure > see 5 chapter.
9		<b>Mains connection cable &gt; see 5.1.6 chapter</b>
10		<b>Connection socket, “-” welding current</b> How to connect the accessories depends on the welding procedure. Please observe the connection description for the corresponding welding procedure > see 5 chapter.
11		<b>Machine control (see the relevant control operating instructions)</b>

## 4.1.1 Connection panel




Figure 4-2

Item	Symbol	Description
1		<b>Connection socket - RJ45 - Option</b> Network connection > see 5.7 chapter
2		<b>Connection socket for hand scanner - optional</b> Component identification Xnet > see 5.9 chapter
3		<b>Key button, Automatic cutout</b> Wire feed motor supply voltage fuse (press to reset a triggered fuse)
4	 DV1	<b>14-pole connection socket</b> Wire feeder control cable connection
5		<b>7-pole connection socket (digital)</b> For connecting digital accessory components
6		<b>8-pole connection socket</b> Cooling unit control lead
7		<b>4-pole connection socket</b> Cooling unit voltage supply
8	 COM	<b>Connection socket (9-pole) - D-Sub</b> PC interface > see 5.8 chapter
9	 analog	<b>Connection socket- 19-pole, analogue - optional</b> Interface for automated welding > see 5.6.1 chapter

## 5 Design and function

### ⚠ WARNING



**Risk of injury from electrical voltage!**

**Contact with live parts, e.g. power connections, can be fatal!**

- Observe the safety information on the first pages of the operating instructions!
- Commissioning must be carried out by persons who are specifically trained in handling power sources!
- Connect connection or power cables while the machine is switched off!

### ⚠ CAUTION



**Risk from electrical current!**

**If welding is carried out alternately using different methods and if a welding torch and an electrode holder remain connected to the machine, the open-circuit/welding voltage is applied simultaneously on all cables.**

- The torch and the electrode holder should therefore always be placed on an insulated surface before starting work and during breaks.

Read and observe the documentation to all system and accessory components!

## 5.1 Transport and installation

### ⚠ WARNING



**Risk of accident due to improper transport of machines that must not be lifted!**

**Do not lift or suspend the machine! The machine can drop and cause injuries! The handles, straps or brackets are suitable for transport by hand only!**

- The machine must not be suspended or lifted using a crane.
- Depending on machine type, equipment for lifting by crane or use while suspended is available as a retrofitting option > see 9 chapter.

### 5.1.1 Ambient conditions



**The machine must not be operated in the open air and must only be set up and operated on a suitable, stable and level base!**

- The operator must ensure that the ground is non-slip and level, and provide sufficient lighting for the place of work.
- Safe operation of the machine must be guaranteed at all times.



**Equipment damage due to contamination!**

**Unusually high amounts of dust, acids, corrosive gases or substances can damage the machine (observe maintenance intervals > see 6.2 chapter).**

- Avoid large amounts of smoke, steam, oily fumes, grinding dust and corrosive ambient air!

#### In operation

Temperature range of the ambient air:

- -25 °C to +40 °C (-13 °F to 104 °F) <sup>[1]</sup>

Relative humidity:

- up to 50 % at 40 °C (104 °F)
- up to 90 % at 20 °C (68 °F)

#### Transport and storage

Storage in a closed room, temperature range of the ambient air:

- -30 °C to +70 °C (-22 °F to 158 °F) <sup>[1]</sup>

Relative humidity

- up to 90 % at 20 °C (68 °F)

<sup>[1]</sup> Ambient temperature dependent on coolant! Observe the coolant temperature range of the torch cooling

## 5.1.2 Machine cooling



**Insufficient ventilation results in a reduction in performance and equipment damage.**

- **Observe the ambient conditions!**
- **Keep the cooling air inlet and outlet clear!**
- **Observe the minimum distance of 0.5 m from obstacles!**

## 5.1.3 Workpiece lead, general

### ⚠ CAUTION



**Risk of burning due to incorrect welding current connection!**

**If the welding current plugs (machine connections) are not locked or if the workpiece connection is contaminated (paint, corrosion), these connections and leads can heat up and cause burns when touched!**

- Check welding current connections on a daily basis and lock by turning to the right when necessary.
- Clean workpiece connection thoroughly and secure properly. Do not use structural parts of the workpiece as welding current return lead!

## 5.1.4 Welding torch cooling system

### 5.1.4.1 Cooling unit connection




Figure 5-1

Item	Symbol	Description
1		<b>4-pole connection socket</b> Cooling unit voltage supply
2		<b>8-pole connection socket</b> Cooling unit control lead
3		<b>Cooling module</b>

- Insert and lock the 4-pole supply plug on the cooling unit into the 4-pole connection socket on the welding machine.
- Insert and lock the 8-pole control lead plug on the cooling unit into the 8-pole connection socket on the welding machine.

## 5.1.5 Connecting the intermediate hose package to the power source



**With this machine series, the earth cable on the intermediate hose package must not be connected to the welding machine or wire feeder! Remove the earth cable or push back into the hose package!**

Some wire electrodes (e.g. self-shielding cored wire) are welded using negative polarity. In this case, the welding current lead should be connected to the "-" welding current socket, and the workpiece lead should be connected to the "+" welding current socket. Observe the information from the electrode manufacturer!




Figure 5-2

Item	Symbol	Description
1		Wire feed unit
2		Intermediate hose package
3		14-pole connection socket Wire feeder control cable
4		Connection socket, "+" welding current <ul style="list-style-type: none"> <li>Standard MIG/MAG welding (intermediate hose package)</li> </ul>
5		Connection socket, "-" welding current <ul style="list-style-type: none"> <li>MIG/MAG cored wire welding: Welding current to wire feed/torch</li> </ul>

- Insert the end of the hose package through the strain relief of the hose package and lock by turning to the right.

**The strain relief for fastening the intermediate hose package is provided on the transport cart used (see corresponding documentation).**

- Insert the welding current cable plug into the relevant welding current connection socket and lock by turning to the right:
  - MIG/MAG cored wire: Welding current "-" connection socket
  - MIG/MAG standard: Welding current "+" connection socket
- Insert the control cable plug into the connection socket (14-pole) and secure with crown nut (the plug can only be inserted into the connection socket in one position).

## 5.1.6 Mains connection

### **⚠ DANGER**



#### **Hazards caused by improper mains connection!**

#### **An improper mains connection can cause injuries or damage property!**

- The connection (mains plug or cable), the repair or voltage adjustment of the device must be carried out by a qualified electrician in accordance with the respective local laws or national regulations!
- The mains voltage indicated on the rating plate must match the supply voltage.
- Only operate machine using a socket that has correctly fitted protective earth.
- Mains plug, socket and lead must be checked by a qualified electrician on a regular basis!
- When operating the generator, always ensure it is earthed as stipulated in the operating instructions. The network created must be suitable for operating machines according to protection class I.



**The welding power source is equipped with an internal clamp device for multiple mains voltages. The currently set mains voltage of the power source must match the supply voltage! The following steps have to be carried out:**

- **Visual inspection - comparison between the currently set mains voltage at the power source and the supply voltage > see 5.1.6.1 chapter**
- **Adaptation and marking of the mains voltage > see 5.1.6.2 chapter**
- **Carry out a safety check after intervention in the machine > see 5.1.6.3 chapter!**

### 5.1.6.1 Visual inspection of the set mains voltage

The set mains voltage is marked on the rating plate and the label on the mains connection cable by a marking. If the marked mains voltage range coincides with the supply voltage, further commissioning may take place. If the specifications for mains and supply voltage do not match, the mains voltage in the machine must be reconnected to the supply voltage > see 5.1.6.2 chapter.

Removed or not clearly identifiable adhesive labels must be replaced!

IEC 60974-1, -10 CL.A		⚠	
5A/14.3V ... 500A/39V			
X	40%	60%	100%
U <sub>0</sub> = 82-98V	I <sub>2</sub>	500A	430A 370A
	U <sub>1</sub>	35.5V	32.5V
40.0 / 40V			
		100%	
U <sub>0</sub> = 87		370A	
		34.8V	
	I <sub>1,off</sub>	23.5A	
		19.6A	
3-5l			
380V-400V			
440V-480V			
Version: 2		L90-005663-00001	

Example of rating plate

	Betrieb an allen TN, TT und IT-Netzen. (Netz mit Schutzleiter) Operates on all TN, TT and IT mains. (Mains supply with a earth conductor)		380 <input checked="" type="checkbox"/>
			400 <input checked="" type="checkbox"/>
			440 <input type="checkbox"/>
			460 <input type="checkbox"/>
			480 <input type="checkbox"/>
		500 <input type="checkbox"/>	

Adhesive label of mains connection cable

Figure 5-3

### 5.1.6.2 Adjusting the power source to the mains voltage

The mains voltage is adapted by replugging the operating voltage plug on the printed circuit board VB xx0 into the power source.

The machine can be reconnected between three voltage ranges:

1. 380 V to 400 V (factory-set)
2. 440 V to 480 V




Figure 5-4

- Switch off machine at the main switch.
- Disconnect mains plug.
- Loosen the fastening screws from the housing cover. Open the housing cover at the side and lift it up.
- Reconnect operating voltage plug (printed circuit board VB xx0) to the corresponding voltage range of the supply voltage (380V/400V ex works).
- Hook housing cover from above into the aluminium continuous casting profile flexFit and secure with fastening screws.
- Install a mains plug which is permissible for the selected mains voltage to the mains cable. Identify the selected mains voltage on the rating plate and on the adhesive label of mains connection cable.

### 5.1.6.3 Re-commissioning

#### **⚠ WARNING**



**Dangers resulting from failure to perform test after conversion!**

**Before reconnection, "Inspection and Testing during Operation" according to IEC/BS EN 60974-4 "Arc welding systems – Inspection and Testing during Operation" has to be performed!**

- Perform test to IEC / DIN EN 60974-4!

## 5.1.6.4 Mains configuration

The machine may be connected to:

- a three-phase system with four conductors and an earthed neutral conductor
- a three-phase system with three conductors of which any one can be earthed, e.g. the outer conductor




Figure 5-5

### Legend

Item	Designation	Colour code
L1	Outer conductor 1	brown
L2	Outer conductor 2	black
L3	Outer conductor 3	grey
N	Neutral conductor	blue
PE	Protective conductor	green-yellow

- Insert mains plug of the switched-off machine into the appropriate socket.

## 5.1.7 Switching on and system diagnosis

Each time the system is switched on, the entire welding system runs data synchronization and the system diagnostics of the individual components. The duration of the start time (switching on up to welding readiness) depends on the number of connected system components and the information to be exchanged under these devices. This time can take from several seconds to several minutes (e.g. for the system components interconnected for the first time). During this start phase, the system components will display the controller type and, if applicable, software information in the welding data display (if available). This start phase is terminated by display of the nominal values for current, voltage or wire feed speed.

### Operation of machine fan and coolant pump

The machine fan and coolant pump in this machine series are temperature- and state-controlled. This ensures that subsystems of the welding machine run only when they are needed. After each switching on, the machine fans run at full power for approx. 2 s, e.g. to blow out dust deposits.



## 5.1.8 Notes on the installation of welding current leads

- Incorrectly installed welding current leads can cause faults in the arc (flickering).
- Lay the workpiece lead and hose package of power sources without HF igniter (MIG/MAG) for as long and as close as possible in parallel.
- Lay the workpiece lead and hose package of power sources with HF igniter (TIG) for as long as possible in parallel with a distance of 20 cm to avoid HF sparkover.
- Always keep a distance of at least 20 cm to leads of other power sources to avoid interferences
- Always keep leads as short as possible! For optimum welding results max. 30 m (welding lead + intermediate hose package + torch lead).




Figure 5-6

- Use an individual welding lead to the workpiece for each welding machine!




Figure 5-7

- Fully unroll welding current leads, torch hose packages and intermediate hose packages. Avoid loops!
- Always keep leads as short as possible!

Lay any excess cable lengths in meanders.




Figure 5-8

## 5.1.9 Stray welding currents

### ⚠ WARNING



**Risk of injury due to stray welding currents!**

**Stray welding currents can destroy protective earth conductors, damage machines and electronic devices and cause overheating of components, leading to fire.**

- Check that all welding current connections are firmly secured and electrical connections are in perfect condition.
- Set up, attach or suspend all conductive power source components such as casing, transport vehicles and crane frames so they are insulated.
- Do not place any other electronic devices such as drills or angle grinders on the power source, transport vehicle or crane frames unless they are insulated.
- Always put welding torches and electrode holders on an insulated surface when they are not in use.




Figure 5-9

## 5.2 MIG/MAG welding

### 5.2.1 Connection for workpiece lead

Some wire electrodes (e.g. self-shielding cored wire) are welded using negative polarity. In this case, the welding current lead should be connected to the "-" welding current socket, and the workpiece lead should be connected to the "+" welding current socket. Observe the information from the electrode manufacturer!




Figure 5-10

Item	Symbol	Description
1		Workpiece
2		"-" welding current connection socket •-----MIG/MAG welding: Workpiece connection
3		Connection socket, "+" welding current •-----MIG/MAG cored wire welding: Workpiece connection

- Insert the plug on the workpiece lead into the "-" welding current connection socket and lock.

### 5.2.2 Welding torch connection

For connection description, see the relevant "Wire feeder" operating instructions.

### 5.2.3 Welding task selection

For selection of the welding task and for general operation see the relevant Control operating instructions.

## 5.3 MMA welding or gouging

### 5.3.1 MMA welding

Manual arc welding or, for short, MMA welding. It is characterised by the fact that the arc burns between a melting electrode and the molten pool. There is no external protection; any protection against the atmosphere comes from the electrode.

### 5.3.2 Air arc gouging

During gouging, an arc burns between a carbon electrode and the workpiece, heating the workpiece until it is molten. At the same time, the molten metal is blown out with compressed air. Special electrode holders with a compressed-air connection and carbon electrodes are required for gouging.

## 5.3.3 Connection of electrode holder or gouging torch

### ⚠ CAUTION



**Risk of crushing and burns!**

**When changing stick electrodes there is a risk of crushing and burns!**

- Wear appropriate and dry protective gloves.
- Use an insulated pair of tongs to remove the used stick electrode or to move welded workpieces.




Figure 5-11

Item	Symbol	Description
1		Electrode holder
2		Gouging torch Note the additional system documents!
3		Connection socket, "+" welding current
4		Connection socket, welding current "-"
5		Workpiece

- Insert the cable plug of the electrode holder or gouging torch into the connection socket, welding current and lock by turning to the right.
- Insert the electrode holder plug and workpiece lead into the welding current socket depending on application and lock in place by turning to the right. The corresponding polarity will be based on the information of the electrode manufacturer on the electrode packaging.

## 5.3.4 Connection of the electrode holder / gouging torch over the wire feeder

Only together with wire feeders and the built-in option of electrode holder connection socket OW MMA.

For connection description, see the relevant "Wire feeder" operating instructions.




Figure 5-12

Item	Symbol	Description
1		Electrode holder
2		Gouging torch Note the additional system documents!
3		Wire feeder Note the additional system documents!
4		Connection socket, "+" welding current
5		Connection socket, welding current "-"
6		Workpiece

- Insert the electrode holder or gouge plug into the welding current connection socket (wire feeder) and lock in place by turning to the right. The welding current polarity is changed by reconnecting the welding power plug (intermediate hose package) at the power source.
- Insert the cable plug on the work piece lead into the "+" welding current connection socket and lock by turning to the right.

## 5.3.5 Welding task selection

For selection of the welding task and for general operation see the relevant Control operating instructions.

## 5.4 TIG welding

### 5.4.1 Connection




Figure 5-13

Item	Symbol	Description
1		<b>Wire feeder</b> Note the additional system documents!
2		<b>Welding torch</b> Observe additional system documents!
3		<b>Connection socket, welding current “-”</b>
4		<b>Workpiece</b>
5		<b>Connection socket, “+” welding current</b>

- Insert the cable plug of the welding current lead (intermediate hose package) into the connection socket, welding current “-” and lock by turning to the right.
- Insert the cable plug on the work piece lead into the “+” welding current connection socket and lock by turning to the right.

### 5.4.2 Welding task selection

For selection of the welding task and for general operation see the relevant Control operating instructions.

## 5.5 Remote control

The remote controls are operated via the 19-pole remote control connection socket (analogue) or the 7-pole remote control connection socket (digital), depending on the model.

Read and observe the documentation to all system and accessory components!

## 5.6 Interfaces for automation

### **WARNING**



**Do not carry out any unauthorised repairs or modifications!**

To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!

**The warranty becomes null and void in the event of unauthorised interference.**

- Appoint only skilled persons for repair work (trained service personnel)!



**Unsuitable control cables or incorrect input/output signal assignment can cause damage to the machine. Use shielded control cables only.**

## 5.6.1 Automation interface

### ⚠ WARNING



**No function of the external interrupt equipment (emergency stop switch)!**  
**If the emergency stop circuit has been set up using an external interrupt equipment connected to the interface for automated welding, the machine must be configured for this setup. If this is not observed, the power source will ignore the external interrupt equipment and will not shut down!**

- Remove jumper 1 on the corresponding control board (to be done only by qualified service personnel)!

These accessory components can be retrofitted as an option > see 9 chapter.

Pin	Input / Output	Name	Figure
<b>A</b>	Output	PE ----- Connection for cable screen	
<b>D</b>	Output (open collector)	IGRO---- Current flows signal I>0 (maximum load 20 mA / 15 V) 0 V = welding current flows	
<b>E/R</b>	Input	Not-Aus- Emergency stop for higher level shut-down of the power source.	
<b>F</b>	Output	0V----- Reference potential	
<b>G/P</b>	Output	IGRO---- Current relay contact to the user, potential-free (max. +/-15 V / 100 mA)	
<b>H</b>	Output	Uist ----- Welding voltage measured against pin F, 0-10 V (0 V = 0 V; 10 V = 100 V) <sup>[1]</sup>	
<b>L</b>	Input	STA/STP Start = 15 V / Stop = 0 V <sup>[2]</sup>	
<b>M</b>	Output	+15 V---- Power supply (max. 75 mA)	
<b>N</b>	Output	-15 V ---- Power supply (max. 25 mA)	
<b>S</b>	Output	0 V----- Reference potential	
<b>T</b>	Output	list----- Welding current measured against pin F; 0-10 V (0 V = 0 A, 10 V = 1000 A) <sup>[3]</sup>	

<sup>[1]</sup> Accuracy type  $\pm (0.05 \text{ V} + 2.5 \% \text{ of the measured value})$

<sup>[2]</sup> The operating mode is specified by the wire feeder (the start / stop function corresponds to the operation of the torch trigger and is used, for instance, in mechanized applications).

<sup>[3]</sup> Accuracy type  $\pm (0.02 \text{ V} + 2.5 \% \text{ of the measured value})$

## 5.6.2 RINT X12 robot interface

The standard digital interface for mechanised applications

### Functions and signals:

- Digital inputs: start/stop, operating modes, JOB and program selection, inching, gas test
- Analogue inputs: control voltages, e.g. for welding performance, welding current, etc.
- Relay outputs: process signal, ready for welding, system composite fault, etc.

## 5.6.3 BUSINT X11 industrial bus interface

The solution for easy integration with automated production with e.g.

- Profinet/Profibus
  - EnthernetIP/DeviceNet
  - EtherCAT
- etc.

## 5.7 Network connection

**This accessory component is only available as a “factory-fit option”.**

The network connection allows the integration of the product into an existing network and exchanging data using the quality-management software Xnet. Some features of the software:

- Real-time display of the welding parameters
- Recording / documentation
- Monitoring of welding parameters
- Maintenance
- Calculations
- WPS management
- Welder management
- xButton management
- Component management

The functionality of the software is in constant development (see the documentation for Xnet).

As standard, welding machines are supplied with a fixed IP address.

Depending on the machine version, the IP address is displayed in the device control or shown on a sticker either below the rating plate or near the control.

**The gateway and the server / computer must be in the same network or IP address range to allow the configuration of the gateway.**

## 5.8 PC interface

### Welding parameter software

Set all welding parameters on the PC and simply transfer to one or more welding machines (accessory, set consisting of software, interface, connection leads)

- Data exchange between power source and PC
- Welding task administration (JOBS)
- Online-data exchange
- Default settings for welding data monitoring
- Update function for new welding parameters

### 5.8.1 Connection



**Equipment damage or faults may occur if the PC is connected incorrectly!**

**Not using the SECINT X10USB interface results in equipment damage or faults in signal transmission. The PC may be destroyed due to high frequency ignition pulses.**

- **Interface SECINT X10USB must be connected between the PC and the welding machine!**
- **The connection must only be made using the cables supplied (do not use any additional extension cables)!**




Figure 5-14

Item	Symbol	Description
1		<b>Connection socket (9-pole) - D-Sub</b> PC interface
2		<b>Connection cable, 9-pole, serial</b>
3		<b>SECINT X10 USB</b>
4		<b>USB connection</b> Connecting a Windows PC to SECINT X10 USB
5		<b>Windows PC</b>



## 5.9 Component identification

**Only together with the device control Expert XQ 2.0 in the LAN gateway or LAN/Wi-Fi gateway version.**

Bar codes predefined in ewm Xnet are recorded with a manual scanner. Component data are retrieved and displayed in the control.

**These accessory components can be retrofitted as an option > see 9 chapter.**

## 6 Maintenance, care and disposal

### 6.1 General

#### **DANGER**



**Risk of injury due to electrical voltage after switching off!**

**Working on an open machine can lead to fatal injuries!**

**Capacitors are loaded with electrical voltage during operation. Voltage remains present for up to four minutes after the mains plug is removed.**

1. Switch off machine.
2. Remove the mains plug.
3. Wait for at least 4 minutes until the capacitors have discharged!

#### **WARNING**



**Incorrect maintenance, testing and repair!**

**Maintenance, testing and repair of the machine may only be carried out by skilled and qualified personnel. A qualified person is one who, because of his or her training, knowledge and experience, is able to recognise the dangers that can occur while testing welding power sources as well as possible subsequent damage, and who is able to implement the required safety procedures.**

Observe the maintenance instructions > see 6.2 chapter.

- In the event that the provisions of one of the below-stated tests are not met, the machine must not be operated again until it has been repaired and a new test has been carried out!

Repair and maintenance work may only be performed by qualified authorised personnel; otherwise the right to claim under warranty is void. In all service matters, always consult the dealer who supplied the machine. Return deliveries of defective equipment subject to warranty may only be made through your dealer. When replacing parts, use only original spare parts. When ordering spare parts, please quote the machine type, serial number and item number of the machine, as well as the type designation and item number of the spare part.

Under the specified ambient conditions and normal working conditions this machine is essentially maintenance-free and requires just a minimum of care.

Contamination of the machine may impair service life and duty cycle. The cleaning intervals depend on the ambient conditions and the resulting contamination of the machine. The minimum interval is every six months.

#### 6.1.1 Cleaning

- Clean the outer surfaces with a moist cloth (no aggressive cleaning agents).
- Purge the machine venting channel and cooling fins (if present) with oil- and water-free compressed air. Compressed air may overspeed and destroy the machine fans. Never direct the compressed air directly at the machine fans. Mechanically block the fans, if required.
- Check the coolant for contaminants and replace, if necessary.

#### 6.1.2 Dirt filter

When using a dirt filter, the cooling air throughput is reduced and the duty cycle of the machine is reduced as a result. The duty cycle decreases with the increasing contamination of the filter. The dirt filter must be removed at regular intervals and cleaned by blowing out with compressed air (depending on the level of soiling).

## 6.2 Maintenance work, intervals

### 6.2.1 Daily maintenance tasks

Visual inspection

- Mains supply lead and its strain relief
- Gas cylinder securing elements
- Check hose package and power connections for exterior damage and replace or have repaired by specialist staff as necessary!
- Gas tubes and their switching equipment (solenoid valve)
- Check that all connections and wearing parts are hand-tight and tighten if necessary.
- Check correct mounting of the wire spool.
- Wheels and their securing elements
- Transport elements (strap, lifting lugs, handle)
- Other, general condition

Functional test

- Operating, message, safety and adjustment devices (Functional test)
- Welding current cables (check that they are fitted correctly and secured)
- Gas tubes and their switching equipment (solenoid valve)
- Gas cylinder securing elements
- Check correct mounting of the wire spool.
- Check that all screw and plug connections and replaceable parts are secured correctly, tighten if necessary.
- Remove any spatter.
- Clean the wire feed rollers on a regular basis (depending on the degree of soiling).

### 6.2.2 Monthly maintenance tasks

Visual inspection

- Casing damage (front, rear and side walls)
- Wheels and their securing elements
- Transport elements (strap, lifting lugs, handle)
- Check coolant tubes and their connections for impurities

Functional test

- Selector switches, command devices, emergency stop devices, voltage reducing devices, message and control lamps
- Check wire guide elements (wire feed roll holder, wire feed nipple, wire guide tube) for tight fit. Recommendation for replacing the wire feed roll holder (eFeed) after 2000 hours of operation, see replacement parts).
- Check coolant tubes and their connections for impurities
- Check and clean the welding torch. Deposits in the torch can cause short circuits and have a negative impact on the welding result, ultimately causing damage to the torch.

### 6.2.3 Annual test (inspection and testing during operation)

A periodic test according to IEC 60974-4 "Periodic inspection and test" has to be carried out. In addition to the regulations on testing given here, the relevant local laws and regulations must also be observed.

For more information refer to the "Warranty registration" brochure supplied and our information regarding warranty, maintenance and testing at [www.ewm-group.com](http://www.ewm-group.com)!

## 6.3 Disposing of equipment



### Proper disposal!

The machine contains valuable raw materials, which should be recycled, and electronic components, which must be disposed of.

- **Do not dispose of in household waste!**
- **Observe the local regulations regarding disposal!**
- According to European provisions (Directive 2012/19/EU on Waste of Electrical and Electronic Equipment), used electric and electronic equipment may no longer be placed in unsorted municipal waste. It must be collected separately. The symbol depicting a waste container on wheels indicates that the equipment must be collected separately.  
This machine has to be disposed of, or recycled, in accordance with the waste separation systems in use.
- According to German law (law governing the distribution, taking back and environmentally correct disposal of electric and electronic equipment (ElektroG)), used machines are to be placed in a collection system separate from unsorted municipal waste. The public waste management utilities (communities) have created collection points at which used equipment from private households can be disposed of free of charge.
- Information about returning used equipment or about collections can be obtained from the respective municipal administration office.
- In addition to this, returns are also possible throughout Europe via EWM sales partners.




## 7 Rectifying faults

All products are subject to rigorous production checks and final checks. If, despite this, something fails to work at any time, please check the product using the following flowchart. If none of the fault rectification procedures described leads to the correct functioning of the product, please inform your authorised dealer.

### 7.1 Error messages (power source)

**The possible error numbers displayed depend on the machine series and version!**

Depending on the options of the machine display, a fault is shown as follows:

Display type - machine control	Display
Graphic display	
two 7-segment displays	
one 7-segment display	

The possible cause of the fault is signalled by a corresponding fault number (see table). In the case of an error, the power unit shuts down.

- Document machine errors and inform service staff as necessary.
- If multiple errors occur, these are displayed in succession.
- Document machine warning and inform service personnel, if required.
- If there are several errors in a control system, the error with the lowest error number (Err) is displayed. If this error is corrected, the next higher error number appears. This process is repeated until all errors have been resolved.

#### Reset error (category legend)



<sup>A</sup> The error message disappears when the error is eliminated.

<sup>B</sup> The error message can be reset by pressing a push-button ◀.

All other error messages can only be reset by switching the machine off and on again.

Error (category)	Possible cause	Remedy
3 <sup>A, B</sup> Tacho error	Wire feed unit interference	Check connections (connections, pipes).
	Permanent overload of the wire drive.	Do not place the liner in tight radii. Check liner for smooth movement.
4 <sup>A</sup> Excess temperature	Power source overheated	Allow the switched on machine to cool down.
	Fan blocked, dirty or defective.	Check fan and clean or replace.
	Air inlet or outlet blocked.	Check air inlet and outlet.
5 Mains overvoltage	Mains voltage too high	Check the mains voltages and compare with the power source connection voltages.

Error (category)	Possible cause	Remedy
7 <sup>B</sup> Low coolant level	low flow rate	Fill coolant.
		Check coolant flow - remove kinks in hose package.
		Adjust flow threshold. <sup>[1]</sup> <sup>[3]</sup>
		Clean water block.
	Pump does not turn	Turn the pump shaft.
	Air in the coolant circuit	Vent coolant circuit.
	Hose package not completely filled with coolant.	Switch the machine off and on again > pump running > filling process.
	Operation with gas-cooled welding torch.	Deactivate torch cooling. Connecting coolant feed and return to hose bridges.
Failure of automatic circuit-breaker <sup>[2]</sup>	Reset automatic circuit-breaker.	
8 <sup>A, B</sup> Shielding gas error	No shielding gas	Check shielding gas supply.
	Pre-pressure too low.	Remove kinks in the hose package (nominal value: 4-6 bar pre-pressure).
9 Overvoltage on secondary	Overvoltage at output: Inverter error	Request service.
10 Earth fault (PE error)	Connection between welding wire and machine casing	Remove electrical connection.
11 <sup>A, B</sup> Fast shut-down	Removing the logical signal "robot ready" during the process.	Eliminate errors on the higher-level control.
16 <sup>A</sup> General pilot arc	Emergency stop circuit error	Check emergency stop circuit.
	Temperature error	See description of error 4.
	Short circuit on welding torch	Check welding torch.
	Request service	
17 <sup>B</sup> Cold wire error	See description of error 3.	See description of error 3.
18 <sup>B</sup> Plasma gas error	Low gas level	See description of error 8.
19 <sup>B</sup> Shielding gas error	Low gas level	See description of error 8.
20 <sup>B</sup> Low coolant level	see description of error 7.	See description of error 7.
22 <sup>A</sup> Excess coolant temperature <sup>[1]</sup>	Coolant overheated <sup>[3]</sup>	Allow the switched on machine to cool down.
	Fan blocked, dirty or defective.	Check fan and clean or replace.
	Air inlet or outlet blocked.	Check air inlet and outlet.
23 <sup>A</sup> Excess temperature of the HF choke	External XF ignition unit overheated	Allow the switched on machine to cool down.
24 <sup>B</sup> Pilot arc ignition error	Pilot arc cannot ignite.	Check welding torch equipment.
25 <sup>B</sup> Forming gas error	Low gas level	See description of error 8.
26 <sup>A</sup> Excess pilot arc module temperature	Pilot arc module overheated	See description of error 4.
32 Error I>0 <sup>[1]</sup>	Current recording faulty	Request service.

Error (category)	Possible cause	Remedy
33 Error UIST <sup>[1]</sup>	Voltage recording faulty	Eliminate short circuit in welding circuit.
		remove external sensor voltage.
		Request service.
34 Electronics error	A/D-channel error	Switch the machine off and on again.
		Request service.
35 Electronics error	Slope error	Switch the machine off and on again.
		Request service.
36  -Error	 -Conditions violated.	Switch the machine off and on again.
		Request service.
37 Electronics error	Temperature error	Allow the switched on machine to cool down.
38 Error IIST <sup>[1]</sup>	Short circuit in welding circuit before welding.	Eliminate short circuit in welding circuit.
		Request service.
39 Electronics error	Secondary overvoltage	Switch the machine off and on again.
		Request service.
40 Electronics error	I>0 error	Request service.
47 <sup>B</sup> Bluetooth error	-	Observe accompanying documentation for Bluetooth function.
48 <sup>B</sup> Ignition error	no ignition at process start (automated machines).	Check wire feeding
		Check load cable connections in welding current circuit.
		clean corroded surfaces on work-piece before welding if necessary.
49 <sup>B</sup> Arc interruption	An arc interruption occurred during welding with an automated system.	Check wire feeding.
		Adjust welding speed.
50 <sup>B</sup> Program number	Internal error	Request service.
51 <sup>A</sup> Emergency stop	The emergency stop circuit of the power source has been activated.	Disable the activation of the emergency stop circuit (release protective circuit).
52 No wire feeder	After switching on the automated system, no wire feeder (DV) was detected.	Check or connect the control lines of the wire feeders;
		Check the identification number of the automated wire feeder (for 1DV: number 1, for 2DV: each a wire feeder with number 1 and a wire feeder with number 2).
53 <sup>B</sup> No wire feeder 2	Wire feeder 2 not detected.	Check control cable connections.
54 VRD error	Open circuit voltage reduction error.	if necessary, disconnect external machine from the welding circuit.
		Request service.
55 <sup>B</sup> Excess wire feeder current	Excess current detected on wire feed mechanism.	Do not place the liner in tight radii.
		Check liner for smooth movement.

Error (category)	Possible cause	Remedy
56 Mains phase failure	One phase of the mains voltage has failed.	Check mains connection, mains plug and mains fuses.
57 <sup>B</sup> Slave tacho error	Wire feeder fault (slave drive).	Check connectors, cables, connections.
	Permanent overload of the wire drive (slave drive).	Do not place the liner in tight radii. Check liner for smooth movement.
58 <sup>B</sup> Short circuit	Check welding circuit for short circuit.	Check welding current circuit.
		Place welding torch on an insulated surface.
59 Incompatible machine	A machine connected to the system is not compatible.	Disconnect incompatible machine from system.
60 Incompatible software	A machine's software is not compatible.	Request service.
61 Welding monitor	The actual value of a welding parameter is outside the specified tolerance field.	Observe tolerance fields.
		Adjust welding parameters.
62 System component <sup>[1]</sup>	System component not found.	Request service.
63 Mains voltage error	Operating and mains voltage are incompatible	Check or adjust operating and mains voltage




<sup>[1]</sup> only for XQ. machine series

<sup>[2]</sup> not for XQ. machine series

<sup>[3]</sup> See technical data for values and other switching thresholds.

## 7.2 Warnings

Depending on the display options of the machine display, a warning message is displayed as follows:

Display type - machine control	Display
Graphic display	
two 7-segment displays	
one 7-segment display	

The cause of the warning is indicated by a corresponding warning number (see table).

- In case of multiple warnings, these are displayed in sequence.
- Document machine warning and inform service personnel, if required.

Warning	Possible cause / remedy
1 Excess temperature	A shutdown is imminent due to excess temperature.
2 Half-wave failures	Check process parameters.
3 Torch cooling warning	Check coolant level and top up if necessary.
4 Shielding gas	Check shielding gas supply.
5 Coolant flow	Check min. flow rate. <sup>[2]</sup>
6 Wire reserve	Only a small amount of wire is left on the spool.
7 CAN-bus failure	Wire feeder not connected; automatic circuit-breaker of wire feed motor (reset the tripped automatic circuit-breaker by actuating).



Warning		Possible cause / remedy
8	Welding circuit	The welding circuit inductance is too high for the selected welding task.
9	WF configuration	Check WF configuration.
10	Partial inverter	One of several partial inverters is not supplying welding current.
11	Excess temperature, coolant <sup>[1]</sup>	Check temperature and switching thresholds. <sup>[2]</sup>
12	Welding monitor	The actual value of a welding parameter is outside the specified tolerance field.
13	Contact error	The resistance in the welding circuit is too high. Check earth connection.
14	Adjustment error	Switch the machine off and on. If the error persists, notify Service.
15	Mains fuse	The power limit of the mains fuse is reached and the welding power is reduced. Check the fuse setting.
16	Protective gas warning	Check the gas supply.
17	Plasma gas warning	Check the gas supply.
18	Forming gas warning	Check the gas supply.
19	Gas warning 4	reserved
20	Coolant temperature warning	Check coolant level and top up if necessary.
21	Excess temperature 2	reserved
22	Excess temperature 3	reserved
23	Excess temperature 4	reserved
24	Coolant flow warning	Check coolant supply. Check coolant level and top up if necessary. Check flow and switching thresholds. <sup>[2]</sup>
25	Flow 2	reserved
26	Flow 3	reserved
27	Flow 4	reserved
28	Wire stock warning	Check wire feeding.
29	Low wire 2	reserved
30	Low wire 3	reserved
31	Low wire 4	reserved
32	Tacho error	Fault of wire feeder - permanent overload of the wire drive.
33	Wire feed motor excess current	Excess current detected on wire feed motor.
34	JOB unknown	JOB selection was not performed because the JOB number is unknown.
35	Wire feed motor slave excess current	Excess current detected on wire feed motor slave (push/push system or intermediate drive).
36	Slave tacho error	Fault of wire feeder - permanent overload of the wire drive (push/push system or intermediate drive).
37	FAST-bus failure	Wire feeder not connected (reset by actuating the automatic cutout of the wire feed motor).
38	Incomplete component information	Check XNET component management.
39	Mains half-wave failure	Check supply voltage.

Warning	Possible cause / remedy
40 Mains undervoltage	Check supply voltage.
41 Cooling module not recognised	Check the cooling unit connection.
47 Battery (Bluetooth remote control)	Battery level is low (replace battery)

[1] only for XQ machine series

[2] See technical data for values and other switching thresholds.

## 7.3 Checklist for rectifying faults

The correct machine equipment for the material and process gas in use is a fundamental requirement for perfect operation!

Legend	Symbol	Description
	↘	Fault/Cause
	✘	Remedy

### Functional errors

- ↘ Mains fuse triggers - unsuitable mains fuse
  - ✘ Set up recommended mains fuse.
- ↘ Machine does not start up after switching on (device fan and possibly coolant pump have no function).
  - ✘ Connect the control cable of the wire feeder.
- ↘ All machine control signal lights are illuminated after switching on
- ↘ No machine control signal light is illuminated after switching on
- ↘ No welding power
  - ✘ Phase failure > check mains connection (fuses)
- ↘ Machine restarts continuously
- ↘ Wire feeder without function
- ↘ System does not start up
  - ✘ Make control lead connections and check that they are fitted correctly.
- ↘ Loose welding current connections
  - ✘ Tighten power connections on the torch and/or on the workpiece
  - ✘ Properly fasten the contact tip and contact tip holder.

### Coolant error/no coolant flowing

- ↘ Insufficient coolant flow
  - ✘ Check coolant level and refill if necessary
- ↘ Air in the coolant circuit
  - ✘ Vent coolant circuit


**Wire feed problems**

- ✓ Contact tip blocked
  - ✘ Clean and, if necessary, replace.
- ✓ Setting the spool brake
  - ✘ Check settings and correct if necessary
- ✓ Setting pressure units
  - ✘ Check settings and correct if necessary
- ✓ Worn wire rolls
  - ✘ Check and replace if necessary
- ✓ Wire feed motor without supply voltage (automatic cutout triggered by overloading)
  - ✘ Reset triggered fuse (rear of the power source) by pressing the key button
- ✓ Kinked hose packages
  - ✘ Extend and lay out the torch hose package
- ✓ Wire guide core or spiral is dirty or worn
  - ✘ Clean core or spiral; replace kinked or worn cores

## 8 Technical data

Performance specifications and guarantee only in connection with original spare and replacement parts!

### 8.1 Dimensions and weighte

	355 XQ	405 XQ	505 XQ
			
Dimensions (l x b x h)	625 x 298 x 531 mm 24.6 x 11.7 x 20.9 inch		
Weight <sup>[1]</sup>	39,4 kg 86.9 lb.		42,7 kg 94.1 lb.

<sup>[1]</sup> All weight indications refer to machine versions with 5 m (16.4 ft) Mains connection cable. For versions with longer mains connection cables, the weight increases.

10 m (32.8 ft) = +1.8 kg (3.9 lb)

15 m (49.2 ft) = +3.6 kg (7.9 lb)

## 8.2 Taurus XQ 355 Synergic

	MIG/MAG	MMA	TIG
Welding current ( $I_2$ )	5 A to 350 A		
Welding voltage according to standard ( $U_2$ )	14,3 V to 31,5 V	20,2 V to 34,0 V	10,2 V to 24,0 V
Duty cycle DC at 40° C <sup>[1]</sup>	350 A (100%)		
Mains voltage <sup>[2]</sup> / Tolerance / mains fuse <sup>[3]</sup>	3 x 380 to 400 V / -25 % to +20 % / 3 x 25 A 3 x 440 to 480 V / -25 % to +15 % / 3 x 20 A		
Frequency	50/60 Hz		
Open circuit voltage ( $U_0$ )	82 V to 98 V		82 V to 102 V
max. Connected load ( $S_1$ )	13,9 kVA	15 kVA	10,6 kVA
Generator rating (Rec.)	20,3 kVA		
Power consumption $P_0$ <sup>[4]</sup>	21 W		
Maximum mains impedance (@PCC) <sup>[5]</sup>	96 mOhm		
Cos $\varphi$ / efficiency	0,99 / 90 %		
Protection class / Overvoltage category	I / III		
Contamination level	3		
Insulation class / protection classification	H / IP 23		
Residual current circuit breaker	Type B (recommended)		
Noise level <sup>[6]</sup>	<70 dB(A)		
Ambient temperature <sup>[7]</sup>	-25 °C to +40 °C		
Machine cooling / Torch cooling	Fan (AF) / gas or water		
Mains connection cable	H07RN-F4G4		
Workpiece lead (min.) / EMC class	70 mm <sup>2</sup> / A		
Safety marking	[S] / CE / ENEC		
Standards used	See declaration of conformity (appliance documents)		

<sup>[1]</sup> Load cycle: 10 min. (60 % DC  $\triangleq$  6 min. welding, 4 min. pause)

<sup>[2]</sup> Multi-voltage device - Adjusting the power source to the mains voltage

<sup>[3]</sup> Safety fuses are recommended DIAZED xxA gG. When using automatic cutouts, the "C" trigger characteristic must be used.

<sup>[4]</sup> Power in idle mode without wire feeder.

<sup>[5]</sup> This welding equipment does not comply with IEC 61000-3-12. When connecting a welding machine to a public low-voltage supply system, the manufacturer or operator has to consult the electricity utilities to make sure the welding machine may be connected.

<sup>[6]</sup> Noise level during idle mode and operation under standard load according to IEC 60974-1 at the maximum operating point.

<sup>[7]</sup> Ambient temperature dependent on coolant! Observe coolant temperature range!

## 8.3 Taurus XQ 405 Synergic

	MIG/MAG	MMA	TIG
Welding current (I <sub>2</sub> )	5 A to 400 A		
Welding voltage according to standard (U <sub>2</sub> )	14,3 V to 34 V	20,2 V to 36,0 V	10,2 V to 26,0 V
Duty cycle DC at 40° C <sup>[1]</sup>	400 A (60 %) 350 A (100 %)		
Mains voltage <sup>[2]</sup> / Tolerance / mains fuse <sup>[3]</sup>	3 x 380 to 400 V / -25 % to +20 % / 3 x 25 A 3 x 440 to 480 V / -25 % to +15 % / 3 x 20 A		
Frequency	50/60 Hz		
Open circuit voltage (U <sub>0</sub> )	82 V to 98 V		82 V to 102 V
max. Connected load (S <sub>1</sub> )	17,2 kVA	18,2 kVA	13,2 kVA
Generator rating (Rec.)	24,6 kVA		
Power consumption P <sub>0</sub> <sup>[4]</sup>	21 W		
Maximum mains impedance (@PCC) <sup>[5]</sup>	96 mOhm		
Cos φ / efficiency	0,99 / 90 %		
Protection class / Overvoltage category	I / III		
Contamination level	3		
Insulation class / protection classification	H / IP 23		
Residual current circuit breaker	Type B (recommended)		
Noise level <sup>[6]</sup>	<70 dB(A)		
Ambient temperature <sup>[7]</sup>	-25 °C to +40 °C		
Machine cooling / Torch cooling	Fan (AF) / gas or water		
Mains connection cable	H07RN-F4G4		
Workpiece lead (min.) / EMC class	70 mm <sup>2</sup> / A		
Safety marking	☐ / CE / ENEC		
Standards used	See declaration of conformity (appliance documents)		

<sup>[1]</sup> Load cycle: 10 min. (60 % DC  $\triangleq$  6 min. welding, 4 min. pause)

<sup>[2]</sup> Multi-voltage device - Adjusting the power source to the mains voltage

<sup>[3]</sup> Safety fuses are recommended DIAZED xxA gG. When using automatic cutouts, the "C" trigger characteristic must be used.


<sup>[4]</sup> Power in idle mode without wire feeder.

<sup>[5]</sup> This welding equipment does not comply with IEC 61000-3-12. When connecting a welding machine to a public low-voltage supply system, the manufacturer or operator has to consult the electricity utilities to make sure the welding machine may be connected.

<sup>[6]</sup> Noise level during idle mode and operation under standard load according to IEC 60974-1 at the maximum operating point.

<sup>[7]</sup> Ambient temperature dependent on coolant! Observe coolant temperature range!

## 8.4 Taurus XQ 505 Synergic

	MIG/MAG	MMA	TIG
Welding current ( $I_2$ )	5 A to 500 A		
Welding voltage according to standard ( $U_2$ )	14,3 V to 39 V	20,2 V to 40 V	10,2 V to 30 V
Duty cycle DC at 40° C <sup>[1]</sup>	500 A (40%) 430 A (60%) 370 A (100%)		
Mains voltage <sup>[2]</sup> / Tolerance / mains fuse <sup>[3]</sup>	3 x 380 to 400 V / -25 % to +20 % / 3 x 25 A 3 x 440 to 480 V / -25 % to +15 % / 3 x 20 A		
Frequency	50/60 Hz		
Open circuit voltage ( $U_0$ )	82 V to 98 V		82 V to 102 V
max. Connected load ( $S_1$ )	24,6 kVA	25,3 kVA	19,0 kVA
Generator rating (Rec.)	34,2 kVA		
Power consumption $P_0$ <sup>[4]</sup>	21 W		
Maximum mains impedance (@PCC) <sup>[5]</sup>	96 mOhm		
Cos $\phi$ / efficiency	0,99 / 90 %		
Protection class / Overvoltage category	I / III		
Contamination level	3		
Insulation class / protection classification	H / IP 23		
Residual current circuit breaker	Type B (recommended)		
Noise level <sup>[6]</sup>	<70 dB(A)		
Ambient temperature <sup>[7]</sup>	-25 °C to +40 °C		
Machine cooling / Torch cooling	Fan (AF) / gas or water		
Mains connection cable	H07RN-F4G4		
Workpiece lead (min.) / EMC class	95 mm <sup>2</sup> / A		
Safety marking			
Standards used	See declaration of conformity (appliance documents)		

<sup>[1]</sup> Load cycle: 10 min. (60 % DC  $\triangleq$  6 min. welding, 4 min. pause)

<sup>[2]</sup> Multi-voltage device - Adjusting the power source to the mains voltage

<sup>[3]</sup> Safety fuses are recommended DIAZED xxA gG. When using automatic cutouts, the "C" trigger characteristic must be used.

<sup>[4]</sup> Power in idle mode without wire feeder.

<sup>[5]</sup> This welding equipment does not comply with IEC 61000-3-12. When connecting a welding machine to a public low-voltage supply system, the manufacturer or operator has to consult the electricity utilities to make sure the welding machine may be connected.

<sup>[6]</sup> Noise level during idle mode and operation under standard load according to IEC 60974-1 at the maximum operating point.

<sup>[7]</sup> Ambient temperature dependent on coolant! Observe coolant temperature range!

## 9 Accessories

Performance-dependent accessories like torches, workpiece leads, electrode holders or intermediate hose packages are available from your authorised dealer.

### 9.1 General accessories

Type	Designation	Item no.
KLF-L1-L2-L3-PE	Label of mains cable	094-023697-00000
DM 842 Ar/CO2 230bar 30l D	Pressure regulator with manometer	394-002910-00030
32A 5POLE/CEE	Machine plug	094-000207-00000

### 9.2 7-pole remote control

Type	Designation	Item no.
RC XQ Expert 2.0 2 m	Expert XQ 2.0 remote control	090-008824-00002
RC XQ Expert 2.0 5 m	Expert XQ 2.0 remote control	090-008824-00005
RC XQ Expert 2.0 10 m	Expert XQ 2.0 remote control	090-008824-00010
RC XQ Expert 2.0 15 m	Expert XQ 2.0 remote control	090-008824-00015
FRV 7POL 0.5 m	Extension/connecting cable	092-000201-00004
FRV 7POL 1 m	Extension/connecting cable	092-000201-00002
FRV 7POL 5 m	Extension/connecting cable	092-000201-00003
FRV 7POL 10 m	Extension/connecting cable	092-000201-00000
FRV 7POL 15M	Extension/connecting cable	092-000201-00005
FRV 7POL 20 m	Extension/connecting cable	092-000201-00001
FRV 7POL 25M	Extension/connecting cable	092-000201-00007

### 9.3 Options

Type	Designation	Item no.
ON Filter TG.04/K.02	Contamination filter for air inlet	092-002698-00000
ON FC CS 405/505	Pedestal for transport with floor conveyors	092-007896-00000
ON WAK CS 405/505	Wheel assembly kit for CS 505	092-007897-00000
ON CS TG.0004	Crane console, transport/ram protection	092-007895-00032
ON TH TG.03/TG.04/TG.11 R	Torch holder, right	092-002699-00000

### 9.4 Transport system

Type	Designation	Item no.
ON WAK TG.03/TG.04/TG.09/K.02	Wheel assembly kit	092-001356-00000
Trolley 35-6	Transport cart	090-008827-00000
Trolley XQ 55-5	Transport cart, assembled	090-008636-00000
Trolley XQ 55-5 TM	Transport cart, partially assembled	090-008636-00001
ON PS Trolley XQ 55-5	Cross arm including pivot support (360 °) for wire feeders	092-004301-00000
ON HS Trolley XQ 55-5 / 55-3	Holder for hose packages and welding torches	092-004302-00000
Trolley 55-6	Transport cart, assembled	090-008825-00000
Trolley 55-6 DF	Transport cart, assembled	090-008826-00000
ON TR Trolley 55-5 / 55-6	Cross arm and holder for wire feeder	092-002700-00000
ON Case	Tool box for mounting to Trolley 55-5/6	092-002899-00000

### 9.5 Welding torch cooling system

Type	Designation	Item no.
cool50-2 U40	Cooling module	090-008603-00502
cool50-2 U42	Cooling unit with reinforced pump	090-008796-00502
HOSE BRIDGE UNI	Tube bridge	092-007843-00000



### 9.5.1 Coolant - type blueCool

Type	Designation	Item no.
blueCool -10 5 l	Coolant up to -10 °C (14 °F), 5 l	094-024141-00005
blueCool -10 25 l	Coolant up to -10 °C (14 °F), 25 l	094-024141-00025
blueCool -30 5 l	Coolant up to -30 °C (22 °F), 5 l	094-024142-00005
blueCool -30 25 l	Coolant up to -30 °C (22 °F), 25 l	094-024142-00025
FSP blueCool	Frost protection tester	094-026477-00000

### 9.5.2 Coolant - type KF

Type	Designation	Item no.
KF 23E-5	Coolant up to -10 °C (14 °F), 5 l	094-000530-00005
KF 23E-200	Coolant (-10 °C), 200 litres	094-000530-00001
KF 37E-5	Coolant up to -20 °C (4 °F), 5 l	094-006256-00005
KF 37E-200	Coolant (-20 °C), 200 l	094-006256-00001
TYP1	Frost protection tester	094-014499-00000

## 9.6 Computer communication

Type	Designation	Item no.
PC300 XQ Set	PC300.Net welding parameter software kit incl. cable and SECINT X10 USB interface	090-008777-00000
ON WLG-EX	Wi-Fi gateway in external casing	090-008790-00502
ON LG-EX	LAN gateway in external casing	090-008789-00502

## 9.7 Component identification

Type	Designation	Item no.
SCAN BC 8Pol	Barcode scanner	090-008823-00000
ON SH TG.04	Scanner holder, left	092-004332-00000

## 10 Appendix

### 10.1 Searching for a dealer

Sales & service partners  
[www.ewm-group.com/en/specialist-dealers](http://www.ewm-group.com/en/specialist-dealers)



"More than 400 EWM sales partners worldwide"